

# SHARP

## OPERATION MANUAL with COOKBOOK



## **R-85STM** **MICROWAVE OVEN** **with TOP & BOTTOM GRILLS** **and CONVECTION**

**900W (IEC 60705)**

### **OPERATION MANUAL**

**This operation manual contains important information which you should read carefully before using your microwave oven.**

#### **IMPORTANT:**

**There may be a serious risk to health if this operation manual is not followed or if the oven is modified so that it operates with the door open.**

**If you require any advice or assistance regarding your Sharp product, please visit our website:**

**[www.sharp.co.uk/customersupport](http://www.sharp.co.uk/customersupport)**


**Customers without Internet access may telephone:**

**08705 274277 (9am - 5pm)  
(01) 676 0648 (from Ireland)**

## CONTENTS


<b>YOUR OVEN AND ACCESSORIES</b> .....	2
<b>CONTROL PANEL</b> .....	3
<b>SAFETY:</b>	
Important Safety Instructions .....	4
Installation .....	4 - 5
<b>OPERATION:</b>	
Heating Category .....	6
How Your Oven Works .....	6
Before Operation .....	7
Microwave Power Levels .....	7
Energy Save Mode .....	8
Setting the Clock .....	9
How to Operate Your Oven .....	10 - 11
Grill Cooking .....	12
Preheating the Oven .....	13
Convection Cooking .....	14
Dual Cooking .....	15 - 16
Instant Cook .....	17 - 18
Express Cook / Express Defrost .....	19 - 21
<b>CONVENIENT FUNCTIONS</b>	
Sequence Cooking .....	22
Less and More .....	23
Kitchen Timer .....	24
Auto Minute .....	24
Information Guide .....	25
<b>COOKING ADVICE:</b>	
Microwave Cooking Advice .....	26 - 27
Suitable Cookware .....	28
Defrosting Advice .....	29
Reheating Advice .....	30
<b>AFTERCARE:</b>	
Cleaning and Maintenance .....	31
Troubleshooting .....	32 - 33
To Replace the Mains Plug .....	34
Calling for Service .....	34
<b>COOKBOOK</b> .....	35 - 62
<b>GUARANTEE</b> .....	63
<b>SPECIFICATIONS</b> .....	64

## YOUR OVEN AND ACCESSORIES



### OVEN:


1. Control panel
2. Oven lamp
3. Door opening button
4. Waveguide cover (DO NOT REMOVE)
5. Bottom grill heating element
6. Turntable motor shaft
7. Oven cavity
8. Door seals and sealing surfaces
9. Door latches
10. Top grill heating element
11. Ventilation openings
12. Outer cabinet
13. Power cord



### ACCESSORIES:

Check to make sure the following accessories are provided:

14. Turntable
15. High rack
16. Low rack



- Place the turntable on to the turntable motor shaft, ensuring it is located firmly.
- To avoid turntable damage, ensure dishes or containers are lifted clear of the turntable rim when removing them from the oven.
- For use of the racks, refer to the grilling, dual grilling and oven sections on pages 12 to 16.

**Never touch the grills when they are hot.**

### NOTES:


- The waveguide cover is fragile. Care should be taken when cleaning inside the oven to ensure that it is not damaged.
- After cooking fatty foods without a cover, always clean the cavity and especially the grill heating elements thoroughly, these must be dry and free from grease. Built-up grease may overheat and begin to smoke or catch fire.
- Always operate the oven with the turntable fitted correctly. This promotes thorough, even cooking. A badly fitted turntable may rattle, may not rotate properly and could cause damage to the oven.
- The turntable rotates clockwise or anti-clockwise. The rotary direction may change each time you start the oven. This does not affect cooking performance.
- When you order accessories, please quote both the **PART NAME** and **MODEL NUMBER** to your dealer or SHARP approved service facility. The model number is located at the bottom of the control panel.



### WARNING:

**The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.**

## CONTROL PANEL



### 1. DIGITAL DISPLAY


#### KEYS:

2. TIME
3. CONV. (°C)
4. COMBI
5. INSTANT COOK
6. EXPRESS COOK
7. EXPRESS DEFROST
8. LESS/MORE
9. INFO
10. START/AUTO MINUTE
11. STOP/CLEAR
12. KITCHEN TIMER/CLOCK SET
13. WEIGHT UP/DOWN
14. MICRO POWER
15. GRILL

### DIGITAL DISPLAY

#### INDICATORS:

1. LESS/MORE
2. INFO
3. MICROWAVE POWER LEVEL
4. WEIGHT
5. MICROWAVE
6. CONVECTION
7. BOTTOM GRILL
8. TOP GRILL
9. COOK
10. DEFROST
11. AUTO



## IMPORTANT SAFETY INSTRUCTIONS

### PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

#### Oven Use:

- The oven is for domestic use only.
- Never operate when empty, except as directed in the 'Grill cooking' section on page 12.
- Do not leave or store anything inside the oven when not in use.
- Never attempt to use the oven with the door open. It is important not to force or tamper with the door safety latches.
- Never operate the oven with any object caught in the door.
- Do not insert fingers or objects in the holes of the door latches or air-vent openings as this may damage the oven and cause an electric shock.
- If water or food drops inside the air vent openings switch the oven off immediately, unplug it and call a SHARP approved service facility. (See page 34).
- Never move the oven while it is operating.
- The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. Care should be taken to avoid touching these areas. To prevent burns, always use thick oven gloves. Before cleaning make sure they are not hot.


**Pacemaker:** If you have a heart pacemaker, consult your doctor or the pacemaker manufacturer prior to oven use.

**WARNING:** Do not allow children to use the oven without supervision until adequate instructions have been given, so that the child is able to use the oven in a safe way and understands the hazards of improper use.

**LIQUIDS:** Microwave heating of beverages can result in delayed eruptive boiling, therefore care has to be taken when handling the container. Stir the liquid prior to and during heating/reheating, let liquid stand for at least 20 seconds in the oven after cooking.

**FIRE:** If smoke is observed, switch off and unplug the appliance and keep the door closed in order to stifle any flames.

## INSTALLATION


**WARNING:**  
 **Inspect the Oven:**

- Check the oven carefully for damage before and regularly after installation.
- Make sure the door closes properly, that it is not misaligned or warped.
- Check the hinges and door safety latches are not broken or loose.
- Ensure the door seal and sealing surfaces are not damaged.
- Inspect the oven interior and door for dents.

**IMPORTANT:**  
 If any damage is apparent, do not operate the oven in any way, until it has been repaired by a SHARP trained engineer. (See page 34 for details).


1. Remove all packing materials including the feature sticker (if present). Do not remove the plastic film from the inside of the oven window as this protects it from dirt. The waveguide cover prevents food and grease from entering the waveguide area where it could cause damage.

**DO NOT REMOVE THE WAVEGUIDE COVER.**



2. The oven door will become hot during cooking. Place or mount the oven so that the bottom of the oven is 85cm or more above the floor. Ensure the surface or mounting position is strong enough to take the oven weight, plus the heaviest item likely to be cooked in the oven.

## INSTALLATION

3. The minimum height of free space necessary above the top surface of the oven is 19cm. 
4. Do not place the oven where heat, moisture or high humidity are generated, (for example, near or above a conventional oven) or near combustible materials (for example, curtains). Do not block or obstruct air vent openings. Do not place objects on top of the oven.
5. Make sure the power supply cord is undamaged (See "ELECTRICAL CONNECTION" opposite).  
**Do not allow the power supply cord to run over any hot or sharp surfaces, such as the hot air vent area at the top rear of the oven.**
6. The socket must be readily accessible so that it can be easily unplugged in an emergency.
7. Do not use the oven outdoors.

### BUILDING-IN-KIT.

An installation frame is available which enables the microwave oven to be integrated within a kitchen unit.

The microwave oven is not designed to be built above or near a conventional oven.

SHARP recommend the use of the build in kit **EBR-47ST**, available from your SHARP dealer. Only the use of this frame will guarantee the quality and safety of the oven.



### **WARNING: THIS APPLIANCE MUST BE EARTHED**

To wire an appropriate plug, follow the wiring code given in 'To replace the mains plug' on page 34.

### ELECTRICAL CONNECTION.

- Do not allow water to come into contact with the power supply cord or plug.
- Insert the plug properly into the socket.
- Do not connect other appliances to the same socket using an adaptor plug.
- If the power supply cord is damaged, it must be replaced by a SHARP approved service facility or a similarly qualified person to avoid a hazard.
- When removing the plug from the socket always grip the plug, never the cord as this may damage the power supply cord and the connections inside the plug.
- If the plug fitted to your oven is a rewirable type and in the event of the socket outlet in your home not being compatible with the plug supplied, remove the plug properly (do not cut off).
- If the plug fitted to your oven is a non-rewirable type and in the event of the socket outlet in your home not being compatible with the plug supplied, cut-off the mains plug.
- Refit with a suitable type, observing the wiring code given in 'To replace the mains plug' on page 34.

### IMPORTANT!

- The fuse from the cut-off plug should be removed and the plug disposed of in a safe manner.
- Under no circumstances should the cut-off plug be inserted into a socket outlet as a serious electric shock may occur.
- The plug must not be used without the fuse cover fitted.
- If you have any doubt about your microwave oven obtain the help of a qualified electrician.
- When replacing the plug please ensure that you use a BSI or ASTA approved plug to BSI 363, this should be fitted with a brown coloured 13 amp fuse approved by BSI or ASTA to BSI 362. If you have any doubt about electrical connection seek the help of a qualified electrician.

## HEATING CATEGORY



Microwave Symbol.

Microwave output power in Watts (based on international (IEC 60705) standard).  
Letter representing the oven heating category.

The heating category (a letter A to E) developed by MAFF (Ministry of Agriculture, Fisheries and Food) with microwave oven and food manufacturers indicates the ability of the oven to heat small quantities of food (up to 500g [1lb 2oz]). It does not represent the general performance of the oven.

OVEN OUTPUT POWER	Less heating time required 600 700 800 900 1000 Watts More heating time required
	Less heating time required A B C D E More heating time required

Food packs carry cooking instructions for heating categories A to E. Follow instructions for the letter corresponding to the oven's heating category. The higher the output power and heating category of the oven the less heating time is required as shown opposite.


## HOW YOUR OVEN WORKS

Microwaves are energy waves, similar to those used for TV and radio signals.

Electrical energy is converted into microwave energy, which is directed into the oven cavity via a waveguide. To prevent food and grease entering the wave guide it is protected by the waveguide cover.

Microwaves cannot pass through metal, because of this the oven cavity is made of metal and there is a fine metal mesh on the door.

During cooking the microwaves bounce off the sides of the oven cavity at random.



Microwaves will pass through certain materials, such as glass and plastic, to heat the food. (See 'Suitable Cookware' on page 28).

Water, sugar and fat in food absorb microwaves which cause them to vibrate. This creates heat by friction, in the same way your hands get warm when you rub them together.

The outer areas of the food are heated by the microwave energy, then the heat moves to the centre by conduction, as it does in conventional cooking. It is important to turn, rearrange or stir food to ensure even heating.

Once cooking is complete, the oven automatically stops producing microwaves.

Standing time is necessary after cooking, as it enables the heat to disperse equally throughout the food.



## BEFORE OPERATION

Your oven comes pre-set in Energy Save Mode (see page 8 for details).

### To operate the oven in Energy Save Mode:

1. Plug in the oven. Nothing will appear on the display at this time.

2. Open the door.  
The display will flash:



3. Close the door.  
The display will show:



**NOTES:** In Energy Save Mode, if you do not operate the oven for 3 minutes or more (i.e. after closing the door, pressing the **STOP/CLEAR** key, or at the end of cooking), you will not be able to operate the oven until you open and close the oven door.

When new, the very first time the grills are used, smoke and odour will be given off.

To avoid this happening when food is being cooked, heat the grills without food for approx. 20 minutes. (Please refer to note on page 12.)

## MICROWAVE POWER LEVELS

Power Level	Press the MICRO POWER key	Percentage
HIGH	x 1	100%
MEDIUM HIGH	x 2	70%
MEDIUM	x 3	50%
MEDIUM LOW (Defrost)	x 4	30%
LOW (Defrost)	x 5	10%

- Your oven has 5 power levels, as shown opposite.
- To change the power level for cooking, enter the cooking time and then press the **MICRO POWER** key.

### Power level:

The microwave power level is varied by the microwave energy switching on and off. When using power levels other than 100% you will be able to hear the microwave energy pulsing on and off as the food cooks or defrosts.

**IMPORTANT:** The microwave power level will cook at 100% unless you press the **MICRO POWER** key to the desired setting.

### Check the power level:

To check the microwave power level during cooking, press the **MICRO POWER** key. As long as your finger is pressing the **MICRO POWER** key the power level will be displayed. The oven continues to count down although the display will show the power level.



**MICRO POWER KEY**

## ENERGY SAVE MODE

Your oven has an Energy Save Mode. This facility saves electricity when the oven is not in use.

- If the oven is not used, it will default to Energy Save Mode after 3 minutes. The display is blank and the oven cannot be operated.
- To operate the oven, open and then close the door. "0" will be displayed and the oven is ready to use.

To cancel Energy Save Mode, set the clock. (Please refer to page 9.)

To cancel the clock, follow the procedure opposite. (This will restart Energy Save Mode.)

### Notes:

- If you unplug your oven at any stage you will have to reset the clock to cancel Energy Save Mode.
- If the clock has been set, cancelling Energy Save Mode, then your oven has a safety feature which prevents **INSTANT COOK** and **START/AUTO MINUTE** key from working if the oven has not been in use for more than 3 minutes. Press the **STOP/CLEAR** key or open and close the door to re-use the oven.

1. Time of day appears on the display.



2. Press the **KITCHEN TIMER/CLOCK SET** key 3 times.



3. Press the **START/AUTO MINUTE** key. The power will be off and the display will show nothing.



## SETTING THE CLOCK

Your oven has a 12 hour clock.

- To select the 12 hour clock, press the **KITCHEN TIMER/CLOCK SET** key twice.



To set the time of day follow the instructions opposite.

### NOTES:

- Press the **STOP/CLEAR** key if you make a mistake during programming.
- If you press any of the **TIME** keys too many times, continue to press the key until the desired time re-appears.
- To check the time of day during a cooking process, press the **KITCHEN TIMER/CLOCK SET** key and the time of day will remain on the display as long as you keep your finger on the key. This does not affect the cooking process.
- If the clock is set, when cooking is complete, the display will show the correct time of day. If the clock has not been set, the display will only show ".0" when cooking is complete.
- If the electrical power supply to your microwave oven is interrupted, the display will intermittently show ".0" after the power is reinstated. If this occurs during cooking, the programme will be erased. The time of day will also be erased.
- When you want to reset the time of day, follow the opposite example again.

- Select the clock.



- Enter the hours by pressing the **TIME** keys.



- Press the **KITCHEN TIMER/CLOCK SET** key once.



- Enter the minutes by pressing the **TIME** keys.



- To start the clock, press the **KITCHEN TIMER/ CLOCK SET** key once.



## HOW TO OPERATE YOUR OVEN

### Opening and closing the door:

To open the oven door, push the door opening button.

### Starting the oven:

Close the door and press the **START/AUTO MINUTE** key.



### Stopping the oven:

If you want to stop the oven during cooking, press the **STOP/CLEAR** key once or open the oven door.



If you want to cancel the cooking programme, press the **STOP/CLEAR** key twice.

Your oven enables you to cook and defrost food using the automatic programmes, or to cook and defrost food manually.

Automatic cooking and defrosting allows you to cook and defrost using preset programmes where the timings have been calculated for you, e.g. **Express Cook** and **Express Defrost**.

Manual cooking and defrosting allows you to cook/defrost foods and weights which are not included in the automatic programmes.

The following are examples of manual cooking and defrosting.

For automatic cooking and defrosting refer to pages 17 - 21.


### MANUAL COOKING

- Enter the cooking time and use microwave power levels 10% to 100% to cook (refer to page 7).
- Stir or turn the food, where possible, 2 - 3 times during cooking, if required.
- After cooking, cover the food and leave to stand, if required.
- Refer to the cooking charts in the cookbook section, pages 37 - 44.

### Example:

To cook for 2 minutes 30 seconds on 70% microwave power.

1. Enter the cooking time by pressing the **1 MIN.** key twice, then the **10 SEC.** key three times.



2. Input the power level by pressing the **MICRO POWER** key twice.



3. Press the **START/AUTO MINUTE** key once to start cooking.



The display will count down through the cooking time.

## HOW TO OPERATE YOUR OVEN

### MANUAL DEFROSTING

- Enter the defrosting time and use microwave power levels 10% or 30% to defrost (refer to page 7).
- Stir or turn the food, where possible, 2 - 3 times during defrosting.
- After defrosting, cover the food in foil and leave to stand until thoroughly defrosted.
- Refer to the defrosting charts in the cookbook section, page 36.

### NOTES FOR MANUAL COOKING AND DEFROSTING:

- When the oven starts, the oven lamp will light and the turntable will rotate clockwise or anti-clockwise.
- Your oven can be programmed up to 99 minutes, 90 seconds (99.90).
- If the door is opened during cooking/defrosting to stir or turn over food, the cooking time on the display stops automatically. The cooking/defrosting time starts to count down again when the door is closed and the **START/AUTO MINUTE** key is pressed.
- When cooking/defrosting is complete, the time of day will reappear on the display, if the clock has been set.
- If you want to know the power level during cooking, press the **MICRO POWER** key. As long as your finger is touching the key, the power level will be displayed.

### Example:

To defrost for 10 minutes on 30% microwave power.

1. Enter the defrosting time by pressing the **10 MIN.** key once.



2. Input the power level by pressing the **MICRO POWER** key 4 times.



3. Press the **START/AUTO MINUTE** key once to start defrosting.



The display will count down through the defrosting time.

## GRILL COOKING

The oven has top and bottom grills which can be used separately or combined. These have one power setting only. The grill is assisted by the turntable which rotates simultaneously to ensure even browning.

Use the racks for grilling small items of food such as bacon, gammon and teacakes, turn over halfway through grilling.

Food can be placed either directly onto the racks, or into a flan dish/heat-resistant plate on the high rack.

To select the grill(s) required (Top, Bottom or Combined), enter the grilling time and follow the table below.

Cooking Mode	Press GRILL key
GRILL-1 (Top Grill)	Once
GRILL-2 (Bottom Grill)	Twice
GRILL-3 (Top and Bottom Grill)	3 Times

**NOTE:** When new, the very first time the grills are used, smoke and odour will be given off. To avoid this happening when food is being cooked, heat the grills without food for approx. 20 minutes.

**NOTES:**

- It is not necessary to preheat the grill before cooking.
- Follow the recommended grilling times and procedures in the charts on page 39 of the cookbook section.
- When browning foods in a deep container, place on the turntable or low rack.
- After cooking is complete the cooling fan will continue working for a short time to lower the temperature of the electrical and mechanical parts. The display may show "NOW COOLING".

**Example:**

To grill for 20 minutes, using GRILL-3.

1. Enter the cooking time by pressing the **10 MIN.** key twice.

10min. x2



2. Select GRILL-3 by pressing the **GRILL** key 3 times.

GRILL x3



3. Press the **START/AUTO MINUTE** key once to start grilling.

START/AUTO MINUTE x1



The display will count down through the grilling time.

## PREHEATING THE OVEN

CONV.  
(°C)

Your oven can be preheated to a desired temperature prior to convection cooking.

### NOTES:

- When the oven reaches the desired temperature, the audible signal will sound and the temperature will be displayed in °C.  
**Do not press the STOP/CLEAR key after opening and closing the door, as this will cancel the Convection mode.**
- The preheated temperature will be maintained for approximately 30 minutes.  
After this time, preheat will be cancelled.
- During preheating and convection cooking, you will hear the cooling fan cycling on and off. This is completely normal and will not affect the cooking.
- You can check the actual temperature during preheating by pressing the **CONV. (°C)** key. The temperature will appear on the display. This will not affect the oven operation.
- If you prefer not to preheat the oven where recommended in the cookbook section, allow extra cooking time.

### Example:

To preheat the oven to 180°C.

1. Enter the temperature by pressing the **CONV. (°C)** key 5 times.



2. Press the **START/AUTO MINUTE** key once to start preheating.



3. When the oven reaches 180°C, the audible signal will sound and the oven will display 180°C. Place food in the oven, enter the desired cooking time and press the **START/AUTO MINUTE** key.



### ⚠ WARNING:

The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

## CONVECTION COOKING

CONV.  
(°C)

Your oven can be programmed to cook with ten different temperatures by combining the top and bottom grills with the convection fan. (Please refer to the notes below.)

The temperatures available in °C are:  
**250°C, 230°C, 220°C, 200°C, 180°C,  
160°C, 130°C, 100°C, 70°C, 40°C.**

- Convection cooking is ideal for roasting and baking.
- When using the **CONVECTION** key, all metal cookware can be used. (See 'Suitable Cookware' on page 28).

### NOTES:

- Follow convection times and procedures in the charts and recipes in the cookbook section.
- Food manufacturers instructions are only a guideline, so cooking times may need to be adjusted.
- Pressing the **CONV. (°C)** key during cooking will display the programmed temperature. This will not affect the programme or cooking time.
- Temperature measurements taken whilst the oven is in convection mode will differ from the displayed level. This is due to the grill elements turning on and off in order to regulate the oven temperature. This will not affect the cooking results as long as the operation manual and cookbook are followed correctly.
- After cooking is complete the cooling fan will continue working for a short time to lower the temperature of the electrical and mechanical parts. The display may show "NOW COOLING".
- Heat generated by the oven during convection cooking may cause the backplate of the oven to discolour. This is completely normal and will not affect the performance of the oven.
- This oven is not suitable for baking Yorkshire Puddings.

### Example:

To cook for 20 minutes at 200°C convection.

1. Enter the cooking time by pressing the **10 MIN.** key twice.

10min. x2



2. Input the temperature by pressing the **CONV. (°C)** key 4 times.

CONV.  
(°C) x4



3. Press the **START/AUTO MINUTE** key once to start cooking.

START  
AUTO MINUTE x1



The display will count down through the cooking time.

### ⚠ WARNING:

The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.



## DUAL COOKING

### COMBI

Dual Cook combines microwave power with convection or grill.

The combination of microwave power with convection or grill reduces cooking time and provides a crisp, brown finish.

There are three Dual Cook modes:

1. Dual-1 - Convection with microwave.
2. Dual-2 - Top grill with microwave.
3. Dual-3 - Bottom grill with microwave.

To select the dual cook mode required, enter the cooking time and follow the table below.

Dual Cook Mode	Press COMBI key
DUAL-1 (Convection and Microwave*)	Once
DUAL-2 (Top Grill and Microwave*)	Twice
DUAL-3 (Bottom Grill and Microwave*)	3 Times

### NOTES:

- Dual Cook is preset with 30% microwave power. If you wish to change the microwave power level, press the **MICRO POWER** key until the desired power level is shown on the display.
- \* You can select power levels 10%, 30%, and 50% for DUAL-1.
- \* You can select power levels 10%, 30%, 50%, 70% and 100% for DUAL-2 and DUAL-3.
- DUAL-1 is preset with 250°C convection. To adjust the convection temperature, press the **CONV. °C** key.

**WARNING:**  
The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

### Example for Microwave and Convection:

To cook for 20 minutes using Dual-1, 230°C, 10% microwave power.


1. Enter the cooking time by pressing the **10 MIN.** key twice

10min. | x2



2. Select Dual-1 by pressing the **COMBI** key once.

COMBI | x1



3. Change the temperature by pressing the **CONV. °C** key once.

CONV. (°C) | x1



4. Change the power level by pressing the **MICRO POWER** key once.

MICRO POWER | x1



5. Press the **START/AUTO MINUTE** key once to start cooking.

START AUTO MINUTE | x1



The display will count down through the cooking time.

## DUAL COOKING


### Example for Microwave and Grill:

To cook for 15 minutes using Dual-2, 50% microwave power.

1. Enter the cooking time by pressing the **10 MIN.** key once and the **1 MIN.** key 5 times.



2. Select Dual-2 by pressing the **COMBI** key twice.



3. Change the power level by pressing the **MICRO POWER** key 4 times.



4. Press the **START/AUTO MINUTE** key once to start cooking.



The display will count down through the cooking time.


### NOTES:

- For DUAL-2 and DUAL-3 it is not necessary to preheat the grill.
- Follow the recommended dual cooking times and procedures in the charts on pages 40 - 43.
- When browning foods in a deep container, place on the turntable or low rack.
- Temperature measurements taken whilst the oven is in convection mode will differ from the displayed level. This is due to the grill elements turning on and off in order to regulate the oven temperature. This will not affect the cooking results as long as the operation manual and cook book are followed correctly.
- After cooking is complete the cooling fan will continue working for a short time to lower the temperature of the electrical and mechanical parts. The display may show "NOW COOLING".

**WARNING:**  
The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

## INSTANT COOK

INSTANT COOK enables you to cook 4 popular foods.



For cooking instructions please refer to the chart on page 18.

Follow the example opposite for details on how to operate this function.

### Example:

To cook three Baked Potatoes.

- Select the menu required by pressing the **BAKED POTATO** key 3 times.



After 2 seconds the oven will start cooking automatically and the display will count down through the cooking time.



### NOTES:

- Press the **MORE** or **LESS** key once within 2 seconds after entering the weight as instructed in the chart.
- When action is required (example, to turn food over), the oven stops, the audible signal sounds and instructions will appear on the display. To continue cooking, press the **START/AUTO MINUTE** key.
- The final food temperature will vary according to the initial food temperature. Check food is thoroughly heated after cooking. If necessary, you can extend the cooking time manually.
- All menus on INSTANT COOK use a combination of microwave power and grill or convection.
- The INSTANT COOK function can only be input within 3 minutes after cooking completion, closing the door or pressing the **STOP/CLEAR** key.

### WEIGHT RANGE:

- Weigh all foods prior to cooking as the labelled weight is only approximate.
- Food weight should be rounded up to the nearest 0.1kg, for example, 0.65kg to 0.7kg.
- You are restricted to cook a weight within the range given in the charts.**
- To cook weights or foods not included in the chart, please refer to the charts in the cookbook section.
- You can enter the weight by holding down or pressing the desired **INSTANT COOK** key until the desired weight is displayed.







### WARNING:

The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

## INSTANT COOK

### INSTANT COOK CHART

MENU	WEIGHT RANGE	COOKING INSTRUCTIONS
 Baked Potatoes	1 - 4 potatoes (pieces) 1 potato = approx. 250g	<ul style="list-style-type: none"> <li>Pierce each potato in several places and place towards the edge of the turntable.</li> <li>After cooking, leave to stand for 2 - 3 minutes.</li> </ul>
 Pizza	0.1kg - 0.9kg (Thin & Crispy or Deep Pan type)	<ul style="list-style-type: none"> <li>Lightly grease the turntable with oil.</li> <li>Remove all packaging and place on the turntable.</li> <li>After cooking, remove from the turntable.</li> </ul> <p><b>NOTE:</b> For Frozen Pizza use the <b>MORE</b> key.</p>
 Chicken Quarters	1 - 4 pieces Leg quarter = 300g Breast quarter = 400g	<ul style="list-style-type: none"> <li>Place chicken quarters, best side down, in a flan dish on the low rack.</li> <li>Turn chicken over when the audible signal sounds.</li> <li>After cooking, stand for 5 minutes, wrapped in aluminium foil.</li> </ul> <p><b>NOTES:</b></p> <ul style="list-style-type: none"> <li>For breast &amp; wing quarters use the <b>MORE</b> key.</li> <li>It is not possible to use the <b>LESS</b> key with this menu.</li> </ul>
 Oven Chips	0.1kg - 0.4kg	<ul style="list-style-type: none"> <li>Spread the chips evenly on the turntable.</li> <li>After cooking, remove from the turntable.</li> </ul> <p><b>NOTES:</b></p> <ul style="list-style-type: none"> <li>For thin oven chips use the <b>LESS</b> key.</li> <li>For thick oven chips use the <b>MORE</b> key.</li> </ul>


- Chilled foods are cooked from 5°C.
- Frozen foods are cooked from -18°C.
- For converting to Lb/oz see the conversion chart on page 35.

## EXPRESS COOK / EXPRESS DEFROST

EXPRESS COOK enables you to cook 6 popular menus from frozen or chilled. Please refer to the chart on pages 20.

EXPRESS DEFROST enables you to defrost 3 popular menus. Please refer to the chart on page 21.

Follow the examples below for details on how to operate these functions.



### EXPRESS COOK Example:

To cook 0.6kg of Roast Beef from frozen.


1. Press the **ROAST BEEF/LAMB** key once to select cooking from frozen.



2. Enter the weight by pressing the **WEIGHT UP** key once.



3. Press the **START/AUTO MINUTE** key once to start cooking.



The display will count down through the cooking time.

### EXPRESS DEFROST Example:

To defrost a 1.8kg Meat Joint.


1. Press the **MEAT JOINT** key once.



2. Enter the weight by pressing the **WEIGHT DOWN** key once.



3. Press the **START/AUTO MINUTE** key once to start defrosting.






The display will count down through the cooking time.

### NOTES:

- If the **DOWN (▼) WEIGHT** key is pressed the display will count down from the highest weight range, each time the key is pressed.
- If the **UP (▲) WEIGHT** key is pressed the display will count up from the lowest weight range, each time the key is pressed.
- You can enter the weight by holding down or pressing the **WEIGHT** keys until the desired weight is displayed.

## EXPRESS COOK / EXPRESS DEFROST

### EXPRESS COOK CHART

MENU	WEIGHT RANGE	COOKING PROCEDURE
Roast Beef/Lamb  <b>x1:</b> Frozen <b>x2:</b> Chilled	0.6kg - 1.8kg	<ul style="list-style-type: none"> <li>Place meat in a flan dish on the low rack.</li> <li>Turn meat over when the audible signal sounds.</li> <li>After cooking, leave meat to stand wrapped in aluminium foil for 10 minutes.</li> </ul> <b>NOTE:</b> Select <b>MORE</b> for well done. It is not possible to use the <b>LESS</b> key for beef/lamb.
Roast Pork  <b>x1:</b> Frozen <b>x2:</b> Chilled	0.6kg - 1.8kg	<ul style="list-style-type: none"> <li>Place meat in a flan dish on the low rack.</li> <li>Turn meat over when the audible signal sounds.</li> <li>After cooking, leave meat to stand wrapped in aluminium foil for 10 minutes.</li> </ul> <b>NOTE:</b> It is not possible to use the <b>LESS</b> key for pork.
Roast Poultry  <b>x1:</b> Frozen <b>x2:</b> Chilled	1.2kg - 1.8kg	<ul style="list-style-type: none"> <li>Pierce skin (chilled only) a few times and place poultry, breast side down, in a flan dish on the low rack.</li> <li>Turn poultry over when the audible signal sounds. When cooking frozen poultry with giblets, remove the giblets at first or second turn over.</li> <li>After cooking, leave poultry to stand wrapped in aluminium foil for 10 minutes.</li> </ul> <b>NOTE:</b> It is not possible to use the <b>LESS</b> key for poultry. This menu is only suitable for cooking whole poultry.

- Chilled foods are cooked from 5°C.
- Frozen foods are cooked from -18°C.
- For converting to Lb/oz see the conversion chart on page 35.



#### **WARNING:**




The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

#### **NOTES FOR EXPRESS COOK / EXPRESS DEFROST:**

- Press the **MORE** or **LESS** keys before pressing the **START/AUTO MINUTE** key as instructed in the charts.
- When action is required (example, to turn food over), the oven stops, the audible signals sound and instructions will appear on the display. To continue cooking, press the **START/AUTO MINUTE** key.
- The final food temperature will vary according to the initial food temperature. Check food is thoroughly heated after cooking. If necessary, you can extend the cooking time manually.
- All menus on EXPRESS COOK use a combination of microwave power and convection.
- Before freezing foods, ensure food is fresh and of good quality.

## EXPRESS COOK / EXPRESS DEFROST

### EXPRESS DEFROST CHART

MENU	WEIGHT RANGE	COOKING PROCEDURE
Meat Joint: Beef/Lamb/Pork 	0.6kg - 1.8kg	<ul style="list-style-type: none"> <li>Place meat in a flan dish on the turntable.</li> <li>Turn meat over when the audible signal sounds.</li> <li>Stand, wrapped in foil, for 60 - 90 minutes until thoroughly defrosted.</li> </ul>
Chicken Quarters 	0.3kg - 1.2kg	<ul style="list-style-type: none"> <li>Place quarters, best side-up, in a flan dish on the turntable.</li> <li>Turn over and rearrange when the audible signal sounds.</li> <li>Stand, wrapped in foil, for 15 - 30 minutes until thoroughly defrosted.</li> </ul>
Whole Poultry 	1.2kg - 1.8kg	<ul style="list-style-type: none"> <li>Place poultry, breast side-up, in a flan dish on the turntable.</li> <li>Turn over when the audible signal sounds.</li> <li>Stand, wrapped in foil, for 60 - 90 minutes until thoroughly defrosted.</li> </ul>

- Frozen foods are defrosted from -18°C.
- For converting to Lb/oz see the conversion chart on page 35.

#### NOTES FOR EXPRESS DEFROST:

- If necessary, shield small areas of meat or poultry with flat pieces of aluminium foil. This will prevent the areas from becoming warm during defrosting. Ensure the foil does not touch the oven walls.
- Do not cook the meat or poultry until thoroughly defrosted.
- Do not use the racks for defrosting.

#### WEIGHT RANGE FOR EXPRESS COOK / EXPRESS DEFROST:

- Weigh all meat and poultry prior to cooking/defrosting as the labelled weight is only approximate.
- Food weight should be rounded up to the nearest 0.1kg, for example, 0.65kg to 0.7kg.
- You are restricted to cook/defrost a weight within the range given in the charts.**
- To cook/defrost weights or foods not included in these charts, please refer to the charts in the cookbook section.

## CONVENIENT FUNCTIONS

### I. SEQUENCE COOKING

This function allows you to cook using up to 4 automatic cooking stages for microwave mode and 2 automatic cooking stages for grill and dual cooking modes.

Once programmed there is no need to interfere with the cooking operation as the oven will automatically move onto the next stage.

#### Example:

To cook for:


5 minutes on 70% microwave power (Stage 1)

6 minutes on Grill-I (Stage 2)

3 minutes on Dual-I, 200°C,  
30% microwave power (Stage 3)

#### STAGE 1

1. Enter the cooking time by pressing the **I MIN.** key 5 times.




2. Input the power level by pressing the **MICRO POWER** key twice.



#### STAGE 2

3. Enter the cooking time by pressing the **I MIN.** key 6 times.




4. Select Grill-I by pressing the **GRILL** key once.



#### STAGE 3


5. Enter the cooking time by pressing the **I MIN.** key 3 times.



6. Select Dual-I by pressing the **COMBI** key once, then change the convection temperature by pressing the **CONV. °C** key 3 times.



7. Press the **START/AUTO MINUTE** key once to start cooking.



**NOTE:** If 100% is required on the final stage, it is not necessary to input the power level.



## CONVENIENT FUNCTIONS

### 2. LESS AND MORE

The **LESS (▼)** and **MORE (▲)** keys enable you to:

- Cook/defrost food for less or more time than the automatic programmes.
- Decrease or increase cooking/defrosting time whilst the oven is in use (manual cooking only).

#### TO USE WITH AUTOMATIC PROGRAMMES:

##### EXPRESS COOK / EXPRESS DEFROST

Press the **LESS (▼)** / **MORE (▲)** key before pressing the **START/AUTO MINUTE** key.

##### INSTANT COOK

Press the **LESS (▼)** / **MORE (▲)** key within 2 seconds after pressing the desired key.

#### Example:

If you prefer Baked Potatoes which are cooked, but still firm, use the **LESS (▼)** key.

Alternatively, if you prefer Baked Potatoes softer, use the **MORE (▲)** key.

#### NOTES:

- If you select MORE the display will show, (▲).
- If you select LESS, the display will show, (▼).
- Some menus cannot use the LESS function. If you select LESS for them, then press the **START/AUTO MINUTE** key,

**ERROR NO LESS SETTING**

will be displayed.

- To cancel LESS / MORE, press the same key again.
- To change MORE to LESS, press the **LESS (▼)** key.
- To change LESS to MORE, press the **MORE (▲)** key.

#### TO USE WITH MANUAL COOKING:

#### Example:

To cook for 10 minutes on 50% microwave power and then decrease the cooking time by 2 minutes.

1. Enter the cooking time by pressing the **10 MIN.** key once.



2. Input the power level by pressing the **MICRO POWER** key 3 times.



3. Press the **START/AUTO MINUTE** key once to start cooking.



4. Reduce the cooking time by pressing the **LESS (▼)** key twice.



The cooking time is reduced by 2 minutes and continues to count down.

#### NOTES:

- The cooking/defrosting time will increase/decrease in multiples of 1 minute.
- The overall time can be extended to a maximum of 99 minutes.

## CONVENIENT FUNCTIONS

### 3. KITCHEN TIMER

Use the KITCHEN TIMER as a minute timer or to monitor the standing time for cooked/defrosted food.

#### NOTES:

- You can enter any time up to 99 minutes, 90 seconds.
- To cancel the KITCHEN TIMER simply press the **STOP/CLEAR** key and the display will return to the time of day, if set.
- The KITCHEN TIMER function cannot be used whilst the oven is in use.


#### Example:

To set the timer for 5 minutes.

1. Press the **KITCHEN TIMER** key once.



2. Enter the desired time by pressing the **1 MIN.** key 5 times.



3. Press the **START/AUTO MINUTE** key once to the timer.



### 4. AUTO MINUTE

AUTO MINUTE enables you:

- To cook on 100% microwave power in multiples of 1 minute.
- To extend cooking time in multiples of 1 minute.

**NOTE:** The overall time can be extended to a maximum of 99 minutes.

**Example:** To cook for 2 minutes, press the **START/AUTO MINUTE** key twice.



## CONVENIENT FUNCTIONS

### 5. INFORMATION GUIDE

The **INFO** key provides a step-by-step information guide to the keys on the oven. Your oven comes set with the Information Guide ON.




There are two options (A and B) when you use the **INFO** key:


#### A. GUIDE OF KEYS allows you to press a key to display information about it.

##### Example:

To display the information for EXPRESS COOK "Frozen Roast Pork".

1. Press the **INFO** key once.

Info will appear on the display.  x1



2. Press the **ROAST PORK** key once to select Frozen Roast Pork.

 x1



##### NOTES:

- The display will flash a series of messages, including weight range and action required during or after cooking, e.g. when to stir or turn food.
- The message will be repeated twice, then the display will return to the time of day, if set.
- If you want to cancel the guide, press the **STOP/CLEAR** key.

#### B. GUIDE ON/OFF allows you to turn the information guide on or off.

1. Press the **INFO** key twice.

 x2



2. Press the **START/AUTO MINUTE** key to turn the information guide on, or, press the **STOP/CLEAR** key to turn the information guide off.

 x1 OR  x1



The display will return to the time of day, if set.

**NOTE:** Whenever Info is lit on the display, it is possible to press the Info key to obtain further information. (This is possible even when the information guide has been turned off.)

## MICROWAVE COOKING ADVICE

Microwaves cook food faster than conventional cooking. It is therefore essential that certain techniques are followed to ensure good results. Many of the following techniques are similar to those used in conventional cooking.

### COOKING ADVICE NOTES:

- **Always attend the oven when in use.**
- **Ensure that the utensils are suitable for use in a microwave oven. (See 'Suitable Cookware' on page 28).**
- Refer to the charts in the cookbook section for recommended cooking times and power levels.



### WARNING:

**Liquids and foods must not be heated in sealed containers or jars/containers with lids on, as pressure will build up inside and may cause the jar/container to explode.**

- Do not place hot foods/utensils on a cold turntable or cold foods/utensils on a hot turntable.
- Only use microwave popcorn within the recommended packaging (follow the manufacturers instructions). Never use oil unless specified by the manufacturer and never cook for longer than instructed.



### WARNING:

Follow instructions in the SHARP operation manual at all times. If you exceed recommended cooking times and use power levels that are too high, food may overheat, burn and, in extreme circumstances, catch fire and damage the oven.

### Cooking Techniques

<p><b>Arrange</b></p>	<p>Place the thickest parts of food towards the outside of the dish. e.g. Chicken drumsticks. Foods that are placed towards the outside of the dish will receive more energy, so cook quicker, than those in the centre.</p>	
<p><b>Cover</b></p>	<p>Certain foods benefit from being covered during microwave cooking, follow recommendations where given (see pages 39 - 47). Use vented microwave cling film or a suitable lid.</p>	
<p><b>Pierce</b></p>	<p>Foods with a shell, skin or membrane must be pierced in several places before cooking or reheating as steam will build up and may cause food to explode. e.g. Potatoes, Fish, Chicken, Sausages.</p>	
<p><b>NOTE: Eggs should not be heated using microwave power as they may explode, even after cooking has ended. e.g. poached, fried, hard boiled.</b></p>		
<p><b>Stir, turn and rearrange</b></p>	<p>For even cooking it is essential to stir, turn and rearrange food during cooking. Always stir and rearrange from the outside towards the centre.</p>	
<p><b>Stand</b></p>	<p>Standing time is necessary after cooking so it enables the heat to disperse equally throughout the food.</p>	

## MICROWAVE COOKING ADVICE

Food Characteristics	
<b>Composition</b>	Foods high in fat or sugar (e.g. Christmas pudding, mince pies) require less heating time. Care should be taken as overheating can lead to fire. Bones in food conduct heat, making the food cook more quickly. Care must be taken so that the food is cooked evenly.
<b>Density</b>	Food density will affect the amount of cooking time needed. Light porous foods, such as cakes or bread, cook more quickly than heavy, dense foods, such as roasts and casseroles.
<b>Quantity</b>	The number of microwaves in your oven remains the same regardless of how much food is being cooked. The cooking time must be increased as the amount of food placed in the oven increases. e.g. Four potatoes will take longer to cook than two.
<b>Size</b>	Small foods and small pieces cook faster than large ones, as microwaves can penetrate from all sides to the centre. For even cooking make all the pieces the same size.
<b>Shape</b>	Foods which are irregular in shape, such as chicken breasts or drumsticks, take longer to cook in the thicker parts. For even cooking, place the thickest parts to the outside of the dish where they will receive more energy. Round shapes cook more evenly than square shapes when microwave cooking.
<b>Temperature of food</b>	The initial temperature of food affects the amount of cooking time needed. Chilled foods will take longer to cook than food at room temperature. The temperature of the container is not a true indication of the temperature of the food or drink. Cut into foods with fillings, for example jam doughnuts, to release heat or steam.



**Face & Hands: Always use oven gloves to remove food or cookware from the oven. Stand back when opening the oven door to allow heat or steam to disperse. When removing covers (such as cling film), opening roasting bags or popcorn packaging, direct steam away from face and hands.**



**Check the temperature of food and drink and stir before serving. Take special care when serving to babies, children or the elderly. The contents of feeding bottles and baby food jars are to be stirred or shaken and the temperature is to be checked before consumption to avoid burns.**

## SUITABLE COOKWARE

To cook/defrost food in a microwave oven, the microwave energy must be able to pass through the container to penetrate the food. Therefore it is important to choose suitable cookware.

Round/oval dishes are preferable to square/oblong ones, as the food in the corners tends to overcook. A variety of cookware can be used as listed below.

Cookware	Microwave Safe	Grill	Dual Cook	Convection	Comments
Aluminium foil Foil Containers	✓ / ✗	✓	✓ / ✗	✓	Small pieces of aluminium foil can be used to shield food from overheating. Keep foil at least 2cm from the oven walls, as arcing may occur. Foil containers are not recommended unless specified by the manufacturer, e.g. Microfoil®, follow instructions carefully.
Browning dishes	✓	✗	✗	✗	Always follow the manufacturers instructions. Do not exceed heating times given. Be very careful as these dishes become very hot.
China and ceramics	✓ / ✗	✗	✓ <small>Dual Conv. only</small>	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, except for those with metallic decoration.
Glassware e.g. Pyrex®	✓	✓	✓	✓	Care should be taken if using fine glassware as it can break or crack if heated suddenly.
Metal	✗	✓	✗	✓	It is not recommended to use metal cookware when using microwave power as it will arc, which can lead to fire.
Plastic/Polystyrene E.g. fast food containers	✓	✗	✗	✓ / ✗	Care must be taken as some containers warp, melt or discolour at high temperatures.
Cling film	✓	✗	✗	✗	Should not touch the food and must be pierced to let the steam escape.
Freezer/Roasting bags	✓	✗	✗	✓ / ✗	Must be pierced to let steam escape. Ensure bags are suitable for microwave or convection use. Do not use plastic or metal ties, as they may melt or catch fire due to the metal arcing.
Paper plates/cups and kitchen paper	✓	✗	✗	✗	Only use for warming or to absorb moisture. Care must be taken as overheating may cause fire.
Straw and wooden containers	✓	✗	✗	✗	Always attend the oven when using these materials as overheating may cause fire.
Recycled paper and newspaper	✗	✗	✗	✗	May contain extracts of metal which will cause 'arcing' and may lead to fire.
Racks	✓	✓	✓	✓	The metal racks supplied have been specially designed for all cooking modes and will not damage the oven.



**WARNING:** When heating food in plastic or paper containers, monitor the oven due to the possibility of ignition.

## DEFROSTING ADVICE

Using your microwave oven is the quickest defrosting method.





It is a simple process but the following instructions are essential to ensure the food is thoroughly defrosted.

- Remove all packaging and wrapping before defrosting.
- To defrost food, use microwave power levels 30% or 10%.
- Please refer to the defrosting chart on page 36 for further information.

<b>Rearrange</b>	Foods that are placed towards the outside of the dish will defrost quicker than foods in the centre. It is therefore essential that the food is rearranged up to 4 times during defrosting. Move closely packed pieces from the outside to the centre and rearrange over-lapping areas. This will ensure that all parts of the food defrosts evenly.
<b>Separate</b>	Foods may be stuck together when removed from the freezer. It is important to separate foods as soon as it is possible during defrosting. e.g. bacon rashers, chicken fillets.
<b>Shield</b>	Some areas of food being defrosted may become warm. To prevent them becoming warmer and starting to cook, these areas can be shielded with small pieces of foil, which reflect microwaves, e.g. legs and wings on a chicken.
<b>Stand</b>	Standing time is necessary to ensure food is thoroughly defrosted. Defrosting is not complete once the food is removed from the microwave oven. Food must stand, covered, for a length of time to ensure the centre has completely defrosted.
<b>Turn over</b>	It is essential that all foods are turned over up to 4 times during defrosting. This is important to ensure thorough defrosting.

## REHEATING ADVICE

For the reheating of foods, follow the advice and guidelines below to ensure food is thoroughly reheated before serving.

<b>Plated meals</b>	<p><b>Remove any poultry or meat portions, reheat these separately, see below.</b></p> <p>Place smaller items of food to the centre of the plate, larger and thicker foods to the edge. Cover with vented microwave cling film and reheat on 50%, stir/rearrange halfway through reheating.</p> <p><b>NOTE:</b> Ensure the food is thoroughly reheated before serving.</p>	
<b>Sliced meat</b>	<p>Cover with vented microwave cling film and reheat on 50%. Rearrange at least once to ensure even reheating.</p> <p><b>NOTE:</b> Ensure the meat is thoroughly reheated before serving.</p>	
<b>Poultry portions</b>	<p>Place thickest parts of the portions to the outside of the dish, cover with vented microwave cling film and reheat on 70%.</p> <p>Turn over halfway through reheating.</p> <p><b>NOTE:</b> Ensure the poultry is thoroughly reheated before serving.</p>	
<b>Casseroles</b>	<p>Cover with vented microwave cling film or a suitable lid and reheat on 50%.</p> <p>Stir frequently to ensure even reheating.</p> <p><b>NOTE:</b> Ensure the food is thoroughly reheated before serving.</p>	

To achieve the best results when reheating, select a suitable microwave power level appropriate to the type of food. e.g. A bowl of vegetables can be reheated using 100%, while a lasagne which contains ingredients that cannot be stirred, should be reheated using 50%.

**NOTES:**

- Remove food from foil or metal containers before reheating.
- Reheating times will be affected by the shape, depth, quantity and temperature of food together with the size, shape and material of the container.



**Never heat liquids in narrow-necked containers, as this could result in the contents erupting from the container and may cause burns.**

- To avoid overheating and fire, special care must be taken when reheating foods with a high sugar or fat content, e.g. mince pies or Christmas pudding.
- Never heat oil or fat for deep frying as this may lead to overheating and fire.
- Canned potatoes should not be heated in the microwave oven, follow the manufacturer's instructions on the can.



**The contents of feeding bottles and baby food jars are to be stirred or shaken and the temperature is to be checked before consumption to avoid burns.**



## CLEANING & MAINTENANCE

### OVEN INTERIOR

- It is important to clean the interior of your microwave oven after each use.
- To clean the oven interior, use a mild detergent solution, such as washing-up liquid, with warm water on a soft cloth.
- Food and liquid splashes will build-up on the oven walls and ceiling. If grease, fat and food debris is allowed to build-up in the oven interior it may overheat, smoke or even catch fire when next using the oven.
- Keep the **waveguide cover** clean at all times. The waveguide cover is constructed from a fragile material and should be cleaned with care (follow the cleaning instructions above).  
NOTE: Excessive soaking may cause disintegration of the waveguide cover. The waveguide cover is a consumable part and without regular cleaning, will need to be replaced.
- Food will release steam during cooking and cause condensation inside the oven and door. It is important to wipe the oven dry. A build-up of condensation will eventually lead to rust forming on the oven interior.
- **Do not allow grease or dirt to build-up on the door seals or areas around the door. This may prevent the door from closing correctly and may cause a leakage of microwaves (follow the cleaning instructions opposite).**
- Ensure the turntable and accessories are cleaned after every use with a mild washing-up liquid solution and dried. This will prevent the build-up of grease and food debris. The turntable and accessories are dishwasher safe.

#### Cleaning tip - For easier cleaning of your oven:

Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% for 10 - 12 minutes. Wipe the oven clean using a soft, dry cloth.

### OUTER CABINET

- Wipe the outside of the microwave oven with a mild detergent solution, such as washing-up liquid, with warm water on a soft cloth.
- The control panel must be wiped clean and dried with the door open, therefore inactivating the oven.

### GRILLS

- It is important to keep the grills clean at all times.
- Food and liquid splashes build-up and stick to the grills, which may cause smoke and possibly fire when next using the oven (follow the cleaning instructions above).

### NOTES:

- Never use spray cleaners, oven pads or abrasive scourers as these damage the surface of the oven.
- A steam cleaner should not be used.
- Take care not to let soapy water drip through the small holes in the oven walls and the cavity floor. Excess water spillage through these holes will cause damage to the oven interior.
- Slight tarnishing of the oven cavity, around the area of the grills, is likely to occur. This is normal and will not affect the ovens performance.
- Failure to maintain your oven in a clean condition could adversely affect the life of the oven and possibly result in a hazardous situation.

#### **⚠ WARNING:**

**The door, outer cabinet, oven cavity, turntable, dishes, accessories and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.**

## TROUBLESHOOTING

If you think the oven is not working properly there are some simple checks you can carry out yourself before calling an engineer. This will help prevent unnecessary service calls if the fault is something simple.

Follow this simple check below:

Place half a cup of water on the turntable and close the door. Programme the oven to cook for 1 minute using 100% microwave power.

1. Does the oven lamp come on when it is cooking?
2. Does the turntable rotate?
3. Does the cooling fan work? (Check by placing your hand above the air vent openings.)
4. After 1 minute does the audible signal sound?
5. Is the water in the cup hot?

Take the cup of water out of the oven and close the door. Programme the oven to cook for 3 minutes using the top and bottom grills.

6. After 3 minutes, do both the grill heating elements become red?

Programme the oven to cook for 3 minutes using the convection on 180°C.

7. After 3 minutes, is the oven cavity hot?

If you answer "NO" to any question first check that the oven is plugged in properly and the fuse has not blown. If there is no fault with either, check against the troubleshooting chart on the following page.

### NOTES:

- If you cook food for more than the standard time (see chart opposite) using the same cooking mode, the oven's safety mechanisms automatically activate. The microwave power level will be reduced or the grill heating elements will turn on and off.
- After manual or automatic cooking using the Grill, Dual Cook or Convection modes, the cooling fan will switch on to cool the oven cavity. When the cooling fan works, the display may show "NOW COOLING". To clear it, press the **STOP/CLEAR** key and the display will return to the time of day, if set. During these modes, the cooling fan will carry on working after you have pressed the **STOP/CLEAR** key. You may feel hot air blowing out of the air-vent openings.

### ⚠ WARNING:

**Never adjust, repair or modify the oven yourself. It is hazardous for anyone other than a SHARP trained engineer to carry out servicing or repairs. This is important as it may involve the removal of covers that provide protection against microwave energy.**

- The door seal stops microwave leakage during oven operation, but does not form an airtight seal. It is normal to see drops of water, light or feel warm air around the oven door. Food with a high moisture content will release steam and cause condensation inside the door which may drip from the oven.
- Repairs and Modifications: Do not attempt to operate the oven if it is not working properly.
- Outer Cabinet & Lamp Access: Never remove the outer cabinet. This is very dangerous due to high voltage parts inside which must never be touched, as this could be fatal. Your oven is not fitted with a lamp access cover. If the lamp fails, do not attempt to replace the lamp yourself, call a SHARP approved service facility.

### IMPORTANT:

If the display is blank and has gone dark, even if the power plug is properly connected, the oven may be in Energy Save Mode. To cancel it, open and then close the oven door, see page 8.

Cooking Mode	Standard Time
Microwave 100% cooking	20 Minutes
Grill-1	30 Minutes
Grill-2	45 Minutes
Grill-3	Top Grill 15 Minutes Btm Grill 15 Minutes
Dual Cook-2	
Microwave 100%	Microwave 20 Minutes Top Grill 15 Minutes
Microwave 10 - 70%	Top Grill 30 Minutes
Dual Cook-3	
Microwave 100%	Microwave 20 Minutes Btm Grill 15 Minutes
Microwave 10 - 70%	Btm Grill 45 Minutes

## TROUBLESHOOTING

### TROUBLESHOOTING CHART


QUERY	ANSWER
Draught circulates around the door.	When the oven is working, air circulates within the cavity. The door does not form an airtight seal so air may escape from the door.
Condensation forms in the oven, and may drip from the door.	The oven cavity will normally be colder than the food being cooked, and so steam produced when cooking will condense on the colder surface. The amount of steam produced depends on the water content of the food being cooked. Some foods, such as potatoes have a high moisture content. Condensation trapped in the door glass should clear after a few hours.
Flashing or arcing from within the cavity when cooking.	Arcing will occur when a metallic object comes into close proximity to the oven cavity during cooking. This may possibly roughen the surface of the cavity, but would not otherwise damage the oven.
Arcing potatoes.	Ensure all "eyes" are removed from the potatoes and that they have been pierced, place directly onto the turntable or in a heat resistant flan dish or similar.
The display is lit but the control panel will not work when pressed.	Check the door is closed properly.
Oven cooks too slowly.	Ensure correct power level has been selected.
Oven makes a noise.	The microwave energy pulses ON and OFF during cooking/defrosting.
Outer cabinet is hot.	The cabinet may become warm to the touch - keep children away.

## TO REPLACE THE MAINS PLUG

The wires in the mains cable are colour coded as shown:

Green and yellow stripes = **EARTH**  
 Blue = **NEUTRAL**  
 Brown = **LIVE**

As the colours in the mains lead of your oven may not correspond with the coloured marking identifying the terminals in your plug, connect the wires as described:

- The green and yellow wire to the plug terminal marked E or  or coloured green or coloured green and yellow.
- The blue wire to the plug terminal marked N or coloured black or coloured blue.
- The brown wire to the plug terminal marked L or coloured red or coloured brown.

Make sure the terminal screws are tight and the cable is held securely by the cable grip where it enters the plug.

Like most appliances in your home, your oven must be connected to a single phase 230-240V, 50Hz alternating current supply.

If you do not make the proper electrical connections you might damage the oven or injure yourself. Neither SHARP nor the supplier will be liable if this happens.



**WARNING: THIS APPLIANCE  
MUST BE EARTHED**

**If you have any doubts about your  
electrical supply ask a qualified  
electrician.**

## CALLING FOR SERVICE

- If you are unable to resolve a problem using the checks covered on the last few pages, **do not attempt to service this microwave oven yourself.**
- Contact the dealer or supplier from whom the oven was purchased in order to obtain service. Where this is not possible, please contact the SHARP Customer Information Centre. Telephone: 08705 274277 (office hours).
- For general information and assistance with oven queries, please contact our **Customer Information Centre:**  
**U.K.:** 08705 274277 (office hours)  
**Ireland:** 01 676 0648 (office hours)  
**Website:** [www.sharp.co.uk/customersupport](http://www.sharp.co.uk/customersupport)
- Replacement accessories may be obtained from our main parts distributor:  
 Willow Vale Electronics Ltd.  
 Telephone: 0121 766 5414

# COOKBOOK

## CONTENTS

<b>INTRODUCTION &amp; CONVERSION CHARTS</b> .....	35
<b>DEFROSTING CHART:</b>	
Meat, Poultry, Fish and Fruit .....	36
<b>COOKING CHART</b>	
Fish, Fresh & Frozen Vegetables and Fruit .....	37
Rice, Pasta and Eggs .....	38
<b>GRILLING CHART</b> .....	39
<b>DUAL - 1 COOKING CHART</b> .....	40
<b>DUAL - 2 COOKING CHART</b> .....	41 - 43
<b>REHEATING CHART</b> .....	44
<b>RECIPES</b> .....	45 - 62

## INTRODUCTION

This Cookbook contains a wide variety of recipes developed specifically for your microwave oven. These will give you successful results and will save time and electricity. The recipes demonstrate the capabilities of your oven and prove that microwave technology is the efficient and effective alternative to conventional cooking. The cookery notes below compliment all cooking procedures in this cookbook and should be read in advance of recipe preparation.

## COOKERY NOTES

- Please weigh all meat and poultry prior to defrosting and cooking, as labelled weights are only approximate.
- Where dishes are covered use vented microwave cling film unless otherwise stated. Where dishes are lined, use greaseproof paper unless otherwise stated.
- Please note that all preparation times and serving quantities are approximate.
- All ingredients are given in both metric and imperial measures. Use either set but not a combination of both measures.
- Cooking times in the charts and recipes are based on standard conditions. Cooking results will vary according to the condition of foods, utensils and the oven. Please check the cooking result and, if necessary, adjust cooking times accordingly.
- Serve all dishes immediately unless otherwise stated.
- Butter and margarine can be interchanged on recipes, as preferred.
- Half-fat, skimmed or full-fat milk may be used in all recipes, as preferred.
- Where it is necessary to blend foods, use a food processor, liquidiser or press through a sieve.
- Chilled foods are to be cooked from 5°C. **DO NOT COOK FROM FROZEN.**
- Ambient/fresh/dried/canned foods are to be cooked from 20°C. **DO NOT COOK FROM FROZEN.**
- Frozen foods are to be cooked from -18°C.

## CONVERSION CHARTS

WEIGHT MEASURES		VOLUME MEASURES		SPOON MEASURES	
15g	1/2oz	30ml	1floz	1.25ml	1/4 teaspoon
25g	1oz	100ml	3floz	2.5ml	1/2 teaspoon
50g	2oz	150ml	5floz (1/4 pint)	5ml	1 teaspoon
100g	4oz	300ml	10floz (1/2 pint)	15ml	1 tablespoon
175g	6oz	600ml	20floz (1 pint)		
225g	8oz				
450g	1lb				

## DEFROSTING CHART

FOOD	DEFROST TIME	MICRO POWER LEVEL	▼ METHOD	● STANDING TIME
<b>Meat Joints (Beef,Lamb,Pork)</b>	22 - 23 Minutes/ 450g	10%	Place in a flan dish. Turn over 4 - 5 times during defrosting. Shield.	60 - 90 Minutes
<b>Minced Meat</b>	5 - 8 Minutes/ 450g	30%	Place on a plate. Turn over 3 - 4 times, removing defrosted mince each time.	15 - 30 Minutes
<b>Steak 2cm (3/4") thick</b>	11 - 12 Minutes/ 450g	30%	Place in a flan dish. Turn 2 - 3 times, separate during defrosting. Shield.	15 - 30 Minutes
<b>Chops and Sausages</b>	16 - 18 Minutes/ 450g	30%	Place in a flan dish. Turn 2 - 3 times, separate during defrosting. Shield.	15 - 30 Minutes
<b>Bacon</b>	11 - 12 Minutes/ 450g	30%	Place on a plate. Separate and rearrange twice during defrosting. Shield.	5 - 10 Minutes
<b>❖ Whole Poultry (Chicken,Turkey,Duck)</b>	20 - 21 Minutes/ 450g	10%	Place in a flan dish. Turn 4 - 5 times, during defrosting. Shield.	60 - 90 Minutes
<b>Chicken Legs</b>	8 - 9 Minutes/ 450g	30%	Place in a flan dish. Turn 2 - 3 times, separate during defrosting. Shield.	25 - 30 Minutes
<b>Chicken/Turkey (Breasts &amp; Fillets)</b>	11 - 12 Minutes/ 450g	30%	Place in a flan dish. Turn 2 - 3 times, separate during defrosting. Shield.	25 - 30 Minutes
<b>Minced Turkey</b>	11 - 12 Minutes/ 450g	30%	Place in a bowl. Turn 3 - 4 times, removing defrosted mince each time.	15 - 20 Minutes
<b>Whole Fish (Trout, Mackerel)</b>	9 Minutes/ 450g	30%	Place in a flan dish. Separate and rearrange twice during defrosting. Shield.	15 - 30 Minutes
<b>Fish Fillets/Steaks</b>	7 - 8 Minutes/ 450g	30%	Place in a flan dish. Separate and rearrange twice during defrosting. Shield.	15 - 30 Minutes
<b>Apples</b>	8 - 9 Minutes/ 450g	30%	Place in a dish. Stir during defrosting. Shield.	15 - 20 Minutes
<b>Blackcurrants/Redcurrants/Raspberries/Blackberries</b>	6 - 7 Minutes/ 450g	30%	Place in a dish. Stir during defrosting. Shield.	15 - 20 Minutes
<b>Gooseberries/Rhubarb/Strawberries</b>	7 - 8 Minutes/ 450g	30%	Place in a dish. Stir during defrosting. Shield.	15 - 20 Minutes
<b>Bread (sliced)</b>	6 Minutes/ 400g	30%	Place on the turntable. Separate and rearrange during defrosting.	5 - 10 Minutes
<b>Pastry (Puff or Shortcrust)</b>	5 Minutes/ 450g	30%	Place on a plate. Turn over half way through defrosting.	10 - 15 Minutes
<b>Meat &amp; Fruit Pies (cooked)</b>	7 - 8 Minutes/ large pie	30%	Remove from foil container. Place in a flan dish.	15 - 20 Minutes

**NOTE:** Do not use the racks for defrosting.

▼ Method: If shielding is necessary, use small pieces of foil.

❖ Poultry: Chicken, turkey and duck must be defrosted without giblets.

● Standing Time: During recommended standing time, wrap or cover food in foil.

## COOKING CHART

FOOD	COOKING TIME	MICRO POWER LEVEL	METHOD	STANDING TIME
<b>Fish Fillets</b>	7 Minutes/ 450g	100%	Place in a single layer in a flan dish. Cover and cook.	2 - 3 Minutes
<b>Whole Fish &amp; Steaks</b>	7 - 8 Minutes/ 450g	100%	Place in a single layer in a flan dish. Cover and cook.	2 - 3 Minutes
<b>Aubergines &amp; Broccoli (fresh)</b>	5 Minutes/ 225g	100%	Slice. Add 30ml (2 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Green Beans and Sprouts (fresh)</b>	5 - 6 Minutes/ 225g	100%	Add 30ml (2 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Cabbage, Carrots, Cauliflower, Celery (fresh)</b>	5 Minutes/ 225g	100%	Slice or break into florets Add 30ml (2 tbsp) water. Cover. Stir halfway through cooking.	2 Minutes
<b>Corn on the Cob (fresh)</b>	6 - 7 Minutes/ 225g	100%	Add 45ml (3 tbsp) water. Cover. Stir halfway through cooking.	2 Minutes
<b>Courgettes &amp; Leeks (fresh)</b>	4 - 5 Minutes/ 225g	100%	Slice. Add 30ml (2 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Parsnips &amp; Spinach (fresh)</b>	5 - 6 Minutes/ 225g	100%	Slice. Add 45ml (3 tbsp) water. Cover. Stir halfway through cooking.	2 Minutes
<b>Potatoes, Jacket (250g/9oz - each) (fresh)</b>	10 - 12 Minutes/ 2 potatoes	100%	Pierce in several places. Place on the edge of the turntable.	5 Minutes
<b>Potatoes, Boiled (old &amp; new - fresh)</b>	9 - 10 Minutes/ 450g	100%	Cut into quarters. Add 60ml (4 tbsp) water. Cover. Stir halfway through cooking.	4 Minutes
<b>Swede &amp; Turnips (fresh)</b>	7 - 8 Minutes/ 225g	100%	Dice. Add 45ml (3 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Beans &amp; Cabbage (green - frozen)</b>	5 - 6 Minutes/ 225g	100%	Place in dish. Add 15ml (1 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Broccoli/ Leaf Spinach /Brussels Sprouts (frozen)</b>	6 - 7 Minutes/ 225g	100%	Place in dish. Add 15ml (1 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Carrots - sliced (frozen)</b>	6 Minutes/ 225g	100%	Place in dish. Add 15ml (1 tbsp) water. Cover dish. Stir halfway through cooking.	3 Minutes
<b>Cauliflower florets (frozen)</b>	5 - 6 Minutes/ 225g	100%	Place in dish. Add 15ml (1 tbsp) water. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Corn on the Cob (frozen)</b>	10 - 11 Minutes/ 2 cobs	100%	Place in dish. Cover dish. Turnover halfway through cooking.	3 Minutes
<b>Peas, Sweetcorn &amp; Mixed Vegetables (frozen)</b>	5 - 6 Minutes/ 225g	100%	Place in dish. Cover dish. Stir halfway through cooking.	2 Minutes
<b>Apples &amp; Rhubarb (fresh)</b>	5 - 6 Minutes/ 450g	100%	Peel & slice. Place in a dish and cover. Stir during cooking.	2 Minutes
<b>Blackberries/ Raspberries/ Redcurrants</b>	5 - 6 Minutes/ 450g	100%	Place in a dish and cover. Stir during cooking.	2 Minutes

## NOTE:

- Prior to cooking fresh vegetables and fruit are at ambient temperature (20°C)
- Frozen vegetables are cooked from -18°C.

## COOKING CHART

FOOD	* COOKING TIME	MICRO POWER LEVEL	▼ METHOD	● STANDING TIME
<b>White rice (long grain)</b>	14 - 15 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g rice. Do not cover. Stir twice during cooking.	2 Minutes
<b>Brown rice</b>	21 - 22 Minutes	70%	Add 400ml (14fl.oz) boiling water/100g rice. Do not cover. Stir twice during cooking.	2 Minutes
<b>DRIED PASTA</b>				
<b>Spaghetti (short cut)</b>	11 - 12 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Macaroni (short cut)</b>	12 - 13 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Tagliatelle</b>	10 - 11 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Pasta shells</b>	11 - 12 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>FRESH PASTA</b>				
<b>Spaghetti/ Tagliatelle</b>	8 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Fusilli/Penne/ Conchiglie/ Farfalle</b>	8 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Ravioli</b>	12 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Tortellini (white)</b>	12 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Tortellini (brown)</b>	14 Minutes	70%	Add 300ml (1/2 pint) boiling water/100g pasta. Do not cover. Stir twice during cooking.	2 Minutes
<b>Scrambled Eggs</b>	15g butter 2 eggs (medium) 30ml (2 tbsp) milk salt & pepper	70%	1 Melt the butter in a bowl on 70% for 30 seconds. 2 Add the eggs, milk and seasoning and mix well. 3 Cook on 70% for 3 minutes, stirring every 30 seconds.	30 Seconds
<b>Omlette</b>	15g butter 4 eggs (medium) 90ml (6 tbsp) milk salt & pepper	100%	1 Whisk together eggs and milk. Season. 2 Place butter in a 25cm flan dish. Heat on 100% for 1 minute, until melted. Coat the dish with the melted butter. 3 Pour omelette mixture into flan dish. Cook on 100% for 2 minutes. Whisk mixture and cook again on 100% for 4 minutes.	

- Ensure you read all cookery notes on page 35.
- Eggs and Fresh Pasta are cooked from chilled (5°C).
- \* Cooking Time: Cooking time is constant for any quantity of rice or pasta, quantity of boiling water has to be adjusted according to quantity of rice or pasta, see Method.
- Standing Time: After standing, rinse rice and pasta in boiling water prior to serving.



## GRILL - 3 COOKING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Tea Cakes and Muffins</b>	4 - 5 Minutes for 1 - 6 halves	Slice in half. Place directly onto the turntable. Turn over halfway through cooking.	GRILL - 3
<b>Crumpets</b>	5 - 6 Minutes for 1 - 6 crumpets	Place directly onto the turntable. Turn over halfway through cooking.	GRILL - 3
<b>Cheese on Toast</b>	6 Minutes for 2 slices	Place bread directly onto the turntable. Grill for 3 minutes. Turn over and cover with 80g (3oz) grated cheese. Grill for 3 minutes.	GRILL - 3
<b>Oven Chips (thin cut)</b>	6 - 7 Minutes for 100g 8 - 9 Minutes for 200g 10 - 11 Minutes for 300g	Place directly onto the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Oven Chips (standard cut)</b>	6 - 7 Minutes for 100g 8 - 9 Minutes for 200g 10 - 11 Minutes for 300g	Place directly onto the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Oven Chips (thick cut)</b>	8 - 9 Minutes for 200g 11 - 12 Minutes for 300g 13 - 14 Minutes for 400g	Place directly onto the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Bacon</b>	9 - 10 Minutes for 1 - 6 rashers	Place in a flan dish on the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Gammon Steak</b>	8 - 9 Minutes for 225g 13 - 14 Minutes for 450g	Place directly onto the turntable. Turn over halfway through cooking.	GRILL - 3
<b>Sausages (thin)</b>	8 Minutes for 225g 12 Minutes for 450g	Pierce skin, place directly onto the turntable. Turn over twice during cooking.	GRILL - 3
<b>Sausages (thick)</b>	9 Minutes for 225g 12 Minutes for 450g	Pierce skin, place directly onto the turntable. Turn over twice during cooking.	GRILL - 3
<b>Beefburgers (chilled)</b>	9 Minutes for 225g (2 burgers)  12 Minutes for 450g (4 burgers)	Place directly onto the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Beefburgers (frozen)</b>	9 Minutes for 225g (4 burgers)  12 Minutes for 450g (8 burgers)	Place directly onto the turntable. Turn over 3/4 of the way through cooking.	GRILL - 3
<b>Fish Fingers (frozen)</b>	10 - 11 Minutes for 1 - 12 fingers	Place directly onto the turntable. Turn over halfway through cooking.	GRILL - 3

- NOTES:**
- Chilled foods are cooked from 5°C.
  - Frozen foods are cooked from -18°C.
  - No standing time is required for the foods in this chart.

## DUAL - I COOKING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Beef (rare) (chilled)</b>	10 - 11 Minutes per 450g	Place on the low rack. Calculate cooking time.	DUAL - I 160°C, 50%
<b>Beef/Lamb (medium) (chilled)</b>	13 - 14 Minutes per 450g	Place on the low rack. Calculate cooking time.	DUAL - I 160°C, 50%
<b>Beef/Lamb (well done) (chilled)</b>	17 - 18 Minutes per 450g	Place on the low rack. Calculate cooking time.	DUAL - I 160°C, 50%
<b>Pork (chilled)</b>	20 - 21 Minutes per 450g	Place on the low rack. Calculate the cooking time.	DUAL - I 160°C, 50%
<b>Poultry* (Max. 3 1/2kg) (chilled)</b>	10 - 11 Minutes per 450g	Place breast side up on the low rack. Stand for 10 minutes after cooking.	DUAL - I 200°C, 50%
<b>Fish (Fillets, Steaks, whole) (chilled)</b>	15 Minutes per 450g	Preheat oven to 200°C. Place in a flan dish on the low rack. Stand for 2 - 3 minutes after cooking.	Preheat 220°C DUAL - I 220°C, 30%
<b>Sausage Rolls (uncooked, frozen)</b>	14 - 15 Minutes for 6 sausage rolls (approx. 50g each)	Preheat oven to 220°C. Glaze and place in a flan dish on the low rack. Stand for 3 - 4 minutes after cooking.	Preheat 220°C DUAL - I 220°C, 30%
<b>Garlic Bread (chilled)</b>	6 Minutes for 1 baguette	Preheat oven to 250°C. Remove any packaging. Place in a flan dish on the low rack. No standing time is required.	Preheat 250°C DUAL - I 250°C, 10%
<b>Garlic Bread (frozen)</b>	6 Minutes for 1 baguette	Preheat oven to 250°C. Remove any packaging. Place in a flan dish on the low rack. No standing time is required.	Preheat 250°C DUAL - I 250°C, 30%
<b>Baked Potatoes</b>	19 - 20 Minutes for 2 potatoes (250g each)	Preheat oven to 250°C. Pierce each potato in several places. Place on the low rack. No standing time is required.	Preheat 250°C DUAL - I 250°C, 50%
<b>Roast Potatoes</b>	30 - 35 Minutes for 675g potatoes	Preheat oven to 250°C. Cut into even sized pieces. Brush with oil. Place in a flan dish on the low rack. No standing time is required.	Preheat 220°C DUAL - I 220°C, 30%

\* For poultry weighing 2.4kg or more, place in a flan dish on the turntable.

**NOTES:**

- Chilled foods are cooked from 5°C.
- Frozen foods are cooked from -18°C.

## DUAL - 2 COOKING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Beef rare (chilled)</b>	10 - 11 Minutes per 450g	Place fat side down in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22).  <b>Stage 1:</b> Cook on 70% throughout cooking time, apart from the last 4 minutes. Turn over, remove juices halfway through Stage 1. <b>Stage 2:</b> Cook on DUAL - 2, 70% for the final 4 minutes of cooking time. Stand for 10 minutes after cooking.	<b>Stage 1:</b> 70% <b>Stage 2:</b> DUAL - 2, 70%
<b>Beef/Lamb medium (chilled)</b>	12 - 13 Minutes per 450g	As above	As above
<b>Beef/Lamb (Well done) (chilled)</b>	16 - 17 Minutes per 450g	As above	As above
<b>Pork (chilled)</b>	17 - 18 Minutes per 450g	Place fat side down in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22).  <b>Stage 1:</b> Cook on 70% throughout, apart from the last 4 minutes. Turn over, remove juices halfway through Stage 1. <b>Stage 2:</b> Cook on DUAL - 2, 70% for the final 4 minutes of cooking time. Stand for 10 minutes after cooking.	<b>Stage 1:</b> 70% <b>Stage 2:</b> DUAL - 2, 70%
<b>Poultry (Max. 1.8kg/4lb) (chilled)</b>	11 - 12 Minutes per 450g	Place breast side down in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22).  <b>Stage 1:</b> Cook on 70% throughout cooking time, apart from the last 3 minutes. Turn over, remove juices halfway through Stage 1. <b>Stage 2:</b> Cook on DUAL - 2, 70% for the final 3 minutes of cooking time. Stand for 10 minutes after cooking.	<b>Stage 1:</b> 70% <b>Stage 2:</b> DUAL - 2, 70%
<b>Chicken Fillets (with skin) (chilled)</b>	10 - 11 Minutes per 450g	Place skin side down in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22).  <b>Stage 1:</b> Cook on 70% for the first half of cooking time. Turn over, remove juices after Stage 1. <b>Stage 2:</b> Cook on DUAL - 2, 70% for the second half of cooking time. Stand for 2 minutes after cooking.	<b>Stage 1:</b> 70% <b>Stage 2:</b> DUAL - 2, 70%
<b>Chicken Legs (chilled)</b>	9 - 10 Minutes per 450g	As above	As above
<b>Chicken Breasts (chilled)</b>	13 - 14 Minutes per 450g	As above	As above

- NOTES:**
- Chilled foods are cooked from 5°C.
  - Frozen foods are cooked from -18°C.
  - No standing time is required for the foods in this chart.

## DUAL - 2 COOKING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Lamb Chops (chilled)</b>	10 Minutes per 450g	Place in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL - 2, 70% throughout, apart from the last 3 minutes. Turn over, remove juices after Stage 1. <b>Stage 2:</b> Cook on GRILL - 1 for the final 3 minutes of cooking time.	<b>Stage 1:</b> DUAL - 2, 70% <b>Stage 2:</b> GRILL - 1
<b>Pork Chops (Boneless) (chilled)</b>	14 Minutes per 450g	Place in a flan dish on the low rack. Calculate the cooking time. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL - 2, 70% throughout, apart from the last 3 minutes. Turn over, remove juices after Stage 1. <b>Stage 2:</b> Cook on GRILL - 1 for the final 3 minutes of cooking time.	<b>Stage 1:</b> DUAL - 2, 70% <b>Stage 2:</b> GRILL - 1
<b>Pork Chops (with bone) (chilled)</b>	16 Minutes per 450g	As above	As above
<b>Crispy Crumb Foods (chilled)</b>	7 - 8 Minutes for 100g	Place in a flan dish on the low rack. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL - 2, 30% for the first half of cooking time. Turn over after Stage 1. <b>Stage 2:</b> Cook on GRILL - 1 for second half of cooking time.	<b>Stage 1:</b> DUAL - 2, 30% <b>Stage 2:</b> GRILL - 1
	11 - 12 Minutes for 300g	As above.	As above.
	14 - 15 Minutes for 500g	As above.	As above.
<b>Crispy Crumb Foods (frozen)</b>	8 - 9 Minutes for 100g	Place in a flan dish on the low rack. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL GRILL - 1, 50% for the first half of cooking time. Turn over after Stage 1. <b>Stage 2:</b> Cook on GRILL - 1 for second half of cooking time.	<b>Stage 1:</b> DUAL GRILL - 1, 50% <b>Stage 2:</b> GRILL - 1
	11 - 12 Minutes for 300g	As above.	As above.
	15 - 16 Minutes for 500g	As above.	As above.
<b>Pizza (thin and deep) (chilled)</b>	4 Mins. 30 Secs. for 200g	Remove all packaging and place directly onto the turntable. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL - 2, 100% for 1 min and 30 secs. <b>Stage 2:</b> Cook on GRILL - 3 for 3 minutes.	<b>Stage 1:</b> DUAL - 2, 100% <b>Stage 2:</b> GRILL - 3
	6 Mins. 30 Secs. for 400g	<b>Stage 1:</b> Cook on DUAL - 2, 100% for 2 Mins and 30 secs. <b>Stage 2:</b> Cook on GRILL - 3 for 4 minutes.	As above.
	8 Mins. 30 Secs. for 800g	<b>Stage 1:</b> Cook on DUAL - 2, 100% for 3 mins and 30 secs. <b>Stage 2:</b> Cook on GRILL - 3 for 5 minutes.	As above.

- NOTES:**
- Chilled foods are cooked from 5°C.
  - Frozen foods are cooked from -18°C.
  - No standing time is required for the foods in this chart.

## DUAL - 2 COOKING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Pizza (thin and deep) (frozen)</b>	4 Mins. 30 Secs. for 200g	Remove all packaging and place directly onto the turntable. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on DUAL - 2, 100% for 1 min and 30 sec. <b>Stage 2:</b> Cook on GRILL - 3 for 3 minutes.	<b>Stage 1:</b> DUAL - 2, 100% <b>Stage 2:</b> GRILL - 3
	6 Mins. 30 Secs. for 400g	<b>Stage 1:</b> Cook on DUAL - 2, 100% for 2 min and 30 sec. <b>Stage 2:</b> Cook on GRILL - 3 for 4 minutes.	As above.
	8 Mins. 30 Secs. for 800g	<b>Stage 1:</b> Cook on DUAL - 2, 100% for 3 min and 30 sec. <b>Stage 2:</b> Cook on GRILL - 3 for 5 minutes.	As above.
<b>Baked Potatoes (fresh)</b>	16 - 17 Minutes for 2 Potatoes (250g each)	Pierce each potato in several places. Place in a flan dish on the low rack. Turn over halfway through cooking time.	DUAL - 2, 50%
<b>Roast Potatoes (fresh)</b>	20 - 25 Minutes for 675g Potatoes	Cut into even sized pieces. Brush with oil. Place in a flan dish on the low rack. Turn over halfway through cooking time.	DUAL - 2, 50%
<b>Garlic Bread (chilled)</b>	5 Minutes for 1 baguette	Remove any packaging. Place in a flan dish on the low rack.	DUAL - 2, 10%
<b>Garlic Bread (frozen)</b>	6 Minutes for 1 baguette	Remove any packaging. Place in a flan dish on the low rack.	DUAL - 2, 30%
<b>Toasted Sandwich</b>	5 Minutes for 1 sandwich	Prepare sandwich: Place two slices of ham and 50g grated cheese between 2 slices of bread and butter. Place sandwich directly onto the turntable. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on GRILL - 3, for 4 minutes. <b>Stage 2:</b> Cook on DUAL - 3, 30% for 1 minute.	<b>Stage 1:</b> GRILL - 3 <b>Stage 2:</b> DUAL - 3, 30%
	6 Minutes for 2 sandwiches	Prepare sandwich: As above, double the ingredients. Place sandwiches directly onto the turntable. Use Sequence cooking. (Page 22). <b>Stage 1:</b> Cook on GRILL - 3, for 4 minutes. <b>Stage 2:</b> Cook on DUAL - 3, 30% for 2 minutes.	As above

- NOTES:**
- Chilled foods are cooked from 5°C.
  - Frozen foods are cooked from -18°C.
  - No standing time is required for the foods in this chart.

## REHEATING CHART

FOOD	COOKING TIME	METHOD	COOKING MODE
<b>Canned foods (soups, beans, vegetables, etc.)</b>	6 - 7 Minutes for 425g can	Remove from the can. Place in a dish, cover. Stir halfway through cooking. Stand for 2 minutes after cooking.	70%
<b>Christmas pudding</b>	40 - 50 seconds for 125g slice	Place in a flan dish. Do not exceed cooking time advised by food manufacturer. Stand for 30 seconds after cooking.	70%
	1 Minute for 175g pudding	As above	70%
	4 - 5 Minutes for 450g pudding	Place in a flan dish. Do not exceed cooking time advised by food manufacturer. Stand for 1 minute after cooking.	70%
<b>Sausage rolls (cooked, chilled approx. 50g (2oz) each)</b>	5 Minutes for 6 sausage rolls	Place in a flan dish on the low rack. Stand for 2 minutes after cooking.	DUAL - I 220°C, 30%
<b>Quiche, (cooked, chilled)</b>	6 Minutes for 225g quiche	Remove foil container. Place in a flan dish on the turntable. Stand for 3 minutes after cooking.	DUAL - I 220°C, 50%
	8 Minutes for 450g quiche		
<b>Meat Pie (cooked, chilled)</b>	8 Minutes for 225g pie	Remove foil container. Place in a flan dish on the low rack. Stand for 3 minutes after cooking.	DUAL - I 250°C, 30%
	12 Minutes for 450g pie		
<b>Fruit Pie (cooked, chilled)</b>	15 - 30 Seconds for 50g - 70g pie	Remove foil container. Place in a flan dish on the turntable. Stand for 1 minute after cooking.	50%
	6 Minutes for 225g pie	Remove foil container. Place in a flan dish on the low rack. Stand for 3 minutes after cooking.	DUAL - I 250°C, 10%
	10 Minutes for 450g pie		
<b>Cornish Pasties (cooked, chilled)</b>	4 Minutes for 175g	Place in a flan dish on the low rack. Stand for 3 minutes after cooking.	DUAL - I 220°C, 50%
	5 Minutes for 225g		
<b>Bread rolls/ Croissants</b>	20 - 30 seconds for 2	Place on the turntable.	70%
<b>Garlic bread (cooked, chilled)</b>	3 Minutes for 1 (25cm) baguette	Place on the turntable, uncovered.	100%
<b>Pizza (cooked, chilled)</b>	4 - 5 Seconds for 125g	Place on a plate, uncovered.	100%
	2 - 3 Minutes for 400g	Place on a plate, uncovered.	
<b>Pizza (cooked, frozen)</b>	2 - 3 Minutes for 125g	Place on a plate, uncovered.	100%
	5 - 6 Minutes for 400g	Place on a plate, uncovered.	

**NOTES:**

- Take care when heating foods with high sugar or fat content, for example, Christmas pudding and mince pies.
- DO NOT EXCEED THE REHEATING TIMES GIVEN IN THE CHART ABOVE.

## RECIPES

### Serves 4 - 6

75g celery, sliced  
125g carrots, chopped  
2 cloves garlic, crushed (see tip, page 48)  
100g leeks, sliced  
125g black eyed beans, cooked  
125g chick peas, chopped  
125g kidney beans, cooked  
100g sweetcorn, canned  
400g chopped tomatoes, canned  
1 pint hot vegetable stock  
salt and pepper to taste

### VEGETABLE & BEAN SOUP

- 1 Place the celery, carrots, garlic and leeks in a 2.5 litre bowl and cook on 100% for 3 minutes.
- 2 Place the remaining ingredients into the bowl and mix well.
- 3 Cook on 50% for 35 minutes, stirring 2 - 3 times during cooking.

### Serves 4

15ml (1 tbsp) sunflower oil  
225g onion, finely chopped  
400g broccoli, broken into small florets  
25g plain flour  
1 litre (1<sup>3</sup>/<sub>4</sub> pints) hot vegetable stock  
300ml (1/2 pint) milk  
225g Double Gloucester cheese, grated  
salt and pepper to taste

### BROCCOLI & CHEESE SOUP

- 1 Place oil, onion and broccoli in a large bowl, mix well. Cover and cook on 100% for 5 minutes.
- 2 Stir in the flour to form a paste, add the stock, milk and cheese, mix well. Cover and cook on 100% for 10 minutes.
- 3 Blend in a food processor. Return to bowl and season. Heat on 70% for 18 minutes, stir 3 - 4 times.

### Serves 2 - 4

50g butter  
50g fresh brown breadcrumbs  
75g cooked ham, finely chopped  
90ml (6 tbsp) double cream  
salt and pepper to taste  
5ml (1 tsp) fresh parsley, chopped  
2 large ripe avocados  
15ml (1 tbsp) lemon juice  
75g Double Gloucester cheese, grated  
fresh parsley sprigs to garnish

### AVOCADO AU GRATIN

- 1 Place the butter in a bowl and heat on 100% for 30 seconds. Stir in the breadcrumbs and ham, add enough cream to bind the mixture. Season with salt and pepper to taste and stir in the parsley.
- 2 Cut the avocados in half, remove the stone and brush the flesh with lemon juice. Fill each avocado half with the breadcrumb mixture.
- 3 Place the avocados in a large flan dish and sprinkle with the grated cheese.
- 4 Place the dish on the low rack, use sequence programming to cook on 100% for 2 minutes, then on GRILL - 1 for 8 minutes until brown and crispy.

### Serves 2 - 3

6 medium open cap mushrooms  
75g butter  
2 cloves garlic, crushed (see tip, page 48)  
75g fresh breadcrumbs  
50g cheese, grated

### CRISPY STUFFED MUSHROOMS

- 1 Remove and chop mushroom stalks. Place mushroom caps on the turntable, open side up.
- 2 Heat butter with garlic on 100% for 1 minute, stir in chopped mushroom stalks and breadcrumbs. Fill mushrooms with mixture, sprinkle with cheese.
- 3 Cook on GRILL - 3 for 10 minutes.

**Stilton stuffed mushrooms:** Omit garlic and grated cheese. Add 100g Stilton crumbled at Stage 2.

## RECIPES

### Serves 4

200g white long grain rice  
600ml (1 pint) hot chicken stock  
2.5ml (1/2 tsp) turmeric  
salt and pepper to taste  
1 red pepper, seeded and sliced  
100g prawns, peeled and cooked  
100g peas  
100g cockles, cooked  
100g mussels, cooked  
100g whole baby corn  
225g chicken, cooked and chopped

### PAELLA

- 1 Place the rice in a large bowl and add the stock, turmeric and seasoning. Cook on 70% for 14 - 15 minutes, until the rice is tender, stir 2 - 3 times during cooking. Drain.
- 2 Stir in the red pepper, prawns, peas, cockles, mussels, baby corn and chicken. Cook on 100% for 8 minutes, stirring after 4 minutes.

### Serves 4

4 salmon steaks (approx. 200g each)  
45ml (3 tbsp) dry white wine  
300ml (1/2 pint) mustard sauce (see page 61)  
sprig of fresh rosemary to garnish

### POACHED SALMON WITH MUSTARD SAUCE

- 1 Place the salmon steaks in a flan dish, pierce in several places and add the wine. Cover and cook on 70% for 12 minutes. Allow to stand whilst preparing the sauce.
- 2 Place salmon steaks in a serving dish, reheat on 70% for 2 minutes. Serve the sauce separately.

### Serves 4

200g canned asparagus, chopped  
350g salmon fillet, cooked, flaked  
200g cream cheese and chives (see tip, page 51)  
salt and pepper to taste  
15ml (1 tbsp) fresh dill, chopped  
450g puff pastry  
1 egg, to glaze

### SALMON & CHEESE PARCELS

- 1 Drain asparagus, place in a bowl with the salmon, cream cheese, seasoning and dill, mix well.
- 2 Preheat the oven to convection 200°C.
- 3 Divide pastry into four and roll out to 17cm squares.
- 4 Place equal amounts of mixture into the centre of each square. Brush edges with egg. Form parcels by folding the corners over the filling. Pinch edges to form a raised edge. Brush with egg. Place in two large, greased flan dishes.
- 5 Place one dish on the low rack, the other on the high rack. Cook on convection 200°C for 20 minutes. Swap the trays over and cook for a further 20 minutes until golden.

### Serves 6

50g butter  
3 cloves garlic, crushed (see tip, page 48)  
250g tiger prawns, cooked and peeled  
5ml (1 tsp) fresh parsley, chopped

### GARLIC PRAWNS

- 1 Heat the butter on 100% for 30 seconds. Stir in the garlic and cook on 100% for a further minute.
  - 2 Stir in the prawns and cook on 50% for 7 minutes, stirring every minute. Sprinkle with parsley to serve.
- Serve in ramekin dishes with French bread.

**Garlic mushrooms:** Substitute prawns with 250g mushrooms, cut into quarters.



## RECIPES

### Serves 4

450g white fish fillets (Cod or Haddock)  
 50g butter  
 275g courgettes, sliced  
 100g mushrooms, sliced  
 450ml (¾ pint) white sauce (see tip, page 61)  
 2.5ml (½ tsp) dried tarragon (see tip, page 55)  
 2.5ml (½ tsp) dried basil (see tip, page 55)  
 10ml (2 tsp) English mustard powder

**TOPPING:**  
 900g potato, peeled and quartered  
 300ml (½ pint) water  
 100g margarine  
 60ml (4 tbsp) milk  
 salt and pepper to taste  
 100g cheddar cheese, grated

### FISH PIE

- 1 Arrange fish in a single layer in a flan dish. Cover and cook on 100% for 7 minutes.
- 2 Place butter, courgettes and mushrooms in a 2.5 litre (approx. 4 pint) casserole dish. Cover and cook on 100% for 3 minutes.
- 3 Break the fish into flakes and add to the vegetables.
- 4 Stir herbs and mustard powder into the sauce.
- 5 Add to fish mixture.
- 6 Place the potatoes into a bowl with 300ml (½ pint) water and cook on 100% for 20 minutes, stirring twice.
- 7 Drain the potatoes and mash with butter, milk and seasoning.
- 8 Spread over the fish mixture and sprinkle with the cheese.
- 9 Place on the low rack and cook on DUAL - 1, 200°C, 30% for 35 minutes.

### Serves 4

5ml (1 tsp) green peppercorns, crushed  
 15ml (1 tbsp) fresh tarragon  
 2.5ml (½ tsp) salt  
 4 fresh tuna steaks (approx. 200g each)  
 juice and grated rind of 2 medium oranges  
 olive oil to sprinkle  
 15ml (1 tbsp) cornflour mixed with  
 15ml (1 tbsp) water

### GRILLED TUNA STEAK WITH ORANGE

- 1 Mix together peppercorns, tarragon and salt. Rub evenly onto the steaks and arrange in a flan dish, add orange juice and rind. Sprinkle generously with oil. Marinade in fridge for 2 - 3 hours.
- 2 Remove fish from the marinade and place in a flan dish.
- 3 Place on the low rack and cook on DUAL - 2, 70% for 10 minutes.
- 4 Stir cornflour mixture into marinade. Heat on 100% for 4 minutes until thickened, stir after 2 minutes.
- 5 Return the fish steaks to the sauce and heat on 70% for 3 - 4 minutes.

Serve with new potatoes and fresh vegetables.

### Serves 2 - 4

4 wooden skewers (see tip, page 53)  
 2 courgettes, cut into 8 chunks  
 4 medium mushrooms, stalks removed  
 450g firm fleshed fish skinned and cut into 16 cubes  
 4 slices of orange  
 2 firm medium tomatoes, halved  
 5ml (1 tsp) fresh dill, chopped  
 50g butter

### FISH KEBABS

- 1 Thread pieces of courgette, mushroom, fish, orange and tomato onto each skewer in a regular sequence. Leave no wood exposed.
- 2 Heat the dill and butter in a small bowl on 100% for 30 seconds. Brush kebabs with the dill butter, place in a flan dish on the low rack.
- 3 Cook on DUAL - 2, 50% for 18 minutes. Turn over and rearrange the kebabs every 6 minutes.

## RECIPES

### Serves 6

225g carrots, diced  
 150g celery, sliced  
 175g onion, finely chopped  
 600g pork, cubed  
 400g chopped tomatoes, canned  
 400g canned apricot halves, drained  
 2 cloves garlic, crushed (see tip below)  
 juice and rind of half a lemon  
 150ml (1/4 pint) hot stock  
 salt and pepper to taste

### CITRUS PORK CASSEROLE

- 1 Place the carrots, celery and onion into a 2.5 litre casserole dish and cook on 100% for 4 minutes.
- 2 Add the remaining ingredients and stir thoroughly.
- 3 Place the dish on the low rack and cook on DUAL - 1, 180°C, 50% for 35 minutes.

### Microwave Tip: Peeling garlic easily

Place 3 - 4 cloves of garlic on the turntable. Heat on 100% for 30 seconds, squeeze at one end until the clove pops out.

### Serves 4

45ml (3 tbsp) vegetable oil  
 150g onion, finely chopped  
 100g celery, finely chopped  
 2 cloves garlic, crushed (see tip above)  
 75g bacon, finely chopped  
 1 bay leaf  
 400g canned, chopped tomatoes  
 30ml (2 tbsp) tomato purée  
 450g lean minced beef  
 15ml (1 tbsp) dried mixed herbs (see tip, page 55)  
 450g canned red kidney beans  
 5 - 15ml (1 - 3 tsp) chilli powder, to taste  
 300ml (1/2 pint) red wine  
 300ml (1/2 pint) hot beef stock  
 salt and pepper to taste

### CHILLI CON CARNE

- 1 Place oil, onion, celery, garlic and bacon into a large bowl, mix well. Cover and cook on 100% for 7 - 8 minutes.
- 2 Add the bay leaf, tomatoes, purée and minced beef to the vegetable mixture. Cook on 100% for 9 - 10 minutes, stir 2 - 3 times during cooking.
- 3 Add herbs, kidney beans, chilli powder, wine and stock. Season, mix well. Cover and cook on 100% for 5 minutes, then for 21 - 22 minutes on 50% until sauce is thick. Stir 2 - 3 times during cooking.

**Sheperds Pie:** Make as above, omit the wine. Place in a dish and top with 700g mashed potato. Place on turntable and cook on DUAL - 2, 70% for 9 - 10 minutes until evenly brown.

### Serves 4

225g lean minced beef, pork or lamb  
 2 cloves garlic, crushed (see tip above)  
 75g onion, chopped  
 2 fresh, green chillis, chopped  
 225g canned, chopped tomatoes  
 100g canned, red kidney beans  
 8 taco shells, pre-cooked  
 175g Cheddar cheese, grated

### MEXICAN TACOS

- 1 Place the mince, garlic and onion in a bowl, mix well. Cook on 100% for 7 - 8 minutes, stir twice.
- 2 Stir in chillis, tomatoes and beans. Cook on 100% for 18 minutes. Place taco shells on kitchen paper on turntable. Heat on 100% for 2 minutes. Fill with chilli bean mixture, sprinkle with cheese.
- 3 Pack tacos together, open end up in a large casserole or flan dish. Place on turntable, cook on DUAL - 2, 30% for 7 - 8 minutes.

## RECIPES

### Serves 4

450g stewing steak, chopped  
 100g kidney, chopped  
 125g onion, chopped  
 2.5ml (1/2 tsp) dried mixed herbs (see tip, page 55)  
 450ml (3/4 pint) beef stock  
 15ml (1 tbsp) cornflour mixed with a little water  
**PASTRY:**  
 225g self-raising flour  
 2.5ml (1/2 tsp) salt  
 5ml (1 tsp) baking powder  
 100g suet  
 150ml (1/4 pint) cold water  
 15ml (1 tbsp) milk to glaze

### STEAK & KIDNEY PUDDING

- 1 Place steak, kidney, onion, mixed herbs and stock in a casserole dish. Cover and cook on 70% for 40 minutes. Stir after half the cooking time and add the cornflour to thicken.
- 2 To make the pastry, place the flour, salt, baking powder and suet in a bowl, mix well.
- 3 Add enough cold water to form a soft dough. Roll out 2/3 of the pastry and use it to line the base and sides of a greased 1.2 litre (2 pint) pudding basin.
- 4 Fill pastry lined basin with meat leaving room for the lid. Roll out remaining pastry, cut out a circle to cover pudding. Brush with milk. Make a slit in the centre. Cover with cling film, pierce and cook on 100% for 14 minutes.

### Serves 6

60ml (4 tbsp) plain flour  
 salt and pepper  
 15ml (1 tbsp) dried mixed herbs (see tip, page 55)  
 500g braising steak, sliced thinly  
 75g streaky bacon rashers, chopped  
 25g butter  
 225g carrots, sliced  
 225g courgettes, sliced  
 100g baby onions, whole  
 225g potatoes, par-boiled and chopped  
 300ml (1/2 pint) hot beef stock  
 300ml (1/2 pint) red wine  
 30ml (2 tbsp) cornflour blended with water

### CASSEROLE

- 1 Mix together the flour, salt, pepper and herbs. Toss the beef and bacon in the seasoned flour until well coated.
- 2 Put the butter in a 2.5 litre (approx. 4 pint) casserole dish and melt on 100% for 30 seconds. Stir in the beef, bacon, carrots, courgettes, onions and potatoes.
- 3 Pour in the beef stock, wine and blended cornflour, mix well. Cover with lid, place on low rack and cook on DUAL - 1, 180°C, 30% for 50 minutes. Stir 2 - 3 times.
- 4 Leave to stand for 5 minutes before serving, so that the meat relaxes to improve the texture.

### Serves 6

30ml (2 tbsp) cornflour  
 150ml (1/4 pint) soured cream  
 45ml (3 tbsp) clear honey  
 45ml (3 tbsp) wholegrain mustard  
 150ml (1/4 pint) white wine  
 900g pork, cubed  
 250g fresh apples, chopped  
 125g onion, chopped  
 175g puff pastry  
 eggwash to glaze

### PORK MUSTARD SURPRISE

- 1 Mix the cornflour and cream together in a 2.5 litre (approx. 4 pint) casserole dish.
- 2 Stir in the honey, mustard, wine and stock thoroughly.
- 3 Add the pork, apples and onion, mixing well.
- 4 Place the dish on the low rack and cook on DUAL - 1, 180°C, 50% for 35 minutes, stirring twice during cooking.
- 5 Roll out the pastry to fit the top of the dish. Cover the filling with the pastry and brush with egg to glaze.
- 6 Place the dish on the low rack and cook on 220°C for 15 minutes.

## RECIPES

### Serves 4

#### MARINADE:

15ml (1 tbsp) groundnut oil  
 15ml (1 tbsp) lemon juice  
 60ml (4 tbsp) satay sauce  
 1 clove garlic, crushed (see tip, page 48)  
 Tabasco sauce to taste  
 450g chicken fillets, cubed  
 4 wooden skewers (see tip, page 53)

### CHICKEN SATAY

- 1 Place all the marinade ingredients in a large bowl, mix well. Stir in the chicken, refrigerate for 2 hours to marinate.
- 2 Thread the chicken onto skewers leaving no wood exposed. Place in a large flan dish on the high rack. Cook on DUAL - 2, 70% for 12 - 14 minutes. Turn over and rearrange skewers every 3 - 4 minutes.

### Serves 4

4 large chicken breast fillets, skinned (approx. 200g each)  
 100g Camembert, finely chopped  
 3 spring onions, finely chopped  
 2.5ml (1/2 tsp) dried parsley  
 salt and pepper to taste  
 cocktail sticks to secure  
 75g Cheddar cheese, grated

### CHICKEN & CAMEMBERT ROLLS

- 1 Open out chicken breasts, flatten with a rolling pin.
- 2 Place Camembert, onions, parsley and seasoning in a bowl, mix well. Place a quarter of the mixture at one end of each breast. Roll up tight and secure with cocktail sticks. Ensure no filling is visible.
- 3 Place the breasts seam side upwards in a flan dish.
- 4 Place on the low rack and cook on DUAL - 2, 70% for 18 minutes, turn over and add cheese after 8 minutes.

Sprinkle with toasted almonds to serve.

#### Microwave Tip: Toasting Almonds

Place 25g (1oz) almonds in a shallow flan dish with a knob of butter, heat on 100% for 3 minutes, stir every minute until golden.

### Serves 6

1 red chilli, chopped  
 2 green chillies, chopped  
 125g onion, chopped  
 2.5cm root ginger, chopped  
 1 piece lemon grass, chopped  
 10ml (2 tsp) paprika  
 2.5ml (1/2 tsp) ground turmeric  
 2.5ml (1/2 tsp) cumin seeds  
 2.5ml (1/2 tsp) coriander seeds  
 30ml (2 tbsp) thai fish sauce  
 6 chicken fillets (approx. 200g each)  
 400ml (14 fl.oz) coconut milk  
 150ml (1/4 pint) hot chicken stock  
 salt and pepper to taste  
 Fresh coriander, chopped, to garnish

### THAI CHICKEN

- 1 Place the chillies, onion, ginger, lemon grass, spices and seeds into a 2.5 litre (approx. 4 pints) casserole dish, mix well and cook on 100% for 3 minutes.
- 2 Add the remaining ingredients, stirring thoroughly.
- 3 Place the dish on the low rack and cook on DUAL - 1, 180°C, 30% for 45 minutes.

Sprinkle with coriander and serve with rice.

## RECIPES

### Serves 4 - 6

125g green peppers, chunks  
 125g red peppers, chunks  
 125g yellow peppers, chunks  
 head of garlic, separate cloves and peel  
 150g onion, sliced  
 800g chicken fillets, cubed  
 400g chopped tomatoes, canned  
 5ml (1 tsp) caster sugar  
 10ml (2 tsp) fresh basil, chopped  
 salt and pepper to taste

### GARLIC CHICKEN

- 1 Place the peppers, garlic, onion and chicken into a 2.5 litre (approx. 4 pints) bowl and cook on 100% for 4 minutes.
- 2 Add the remaining ingredients and mix well.
- 3 Place on the low rack, cook on DUAL - 1, 180°C, 30% for 45 minutes, stirring 3 - 4 times during cooking.

Garnish with black olives and fresh basil.

### Serves 4

4 chicken fillets (200g each)  
 45ml (3 tbsp) clear honey  
 5ml (1 tsp) whole grain mustard  
 2.5ml (1/2 tsp) dried tarragon (see tip, page 55)  
 15ml (1 tbsp) tomato purée  
 150ml (1/4 pint) chicken stock  
 15ml (1 tbsp) cornfour  
 salt and pepper

### HONEYED CHICKEN

- 1 Place the chicken breasts in a casserole dish.
- 2 Mix all remaining ingredients together and pour over the chicken.
- 3 Cook on 70% for 22 minutes. Turnover and coat the chicken with the sauce several times during cooking.

#### Microwave Tip: Softening crystallised honey

Place 100g honey in a bowl. Heat on 100% for 1 minute until runny.

#### Microwave Tip: Softening cream cheese

Place 225g cream cheese on a plate. Heat on 30% for 1 minute until soft.

### Serves 4

600g chicken, cubed  
 225g button mushrooms, sliced  
 225g leeks, sliced  
 salt and pepper  
 50g butter  
**SAUCE:**  
 25g butter  
 25g plain flour  
 5ml (1/2 tsp) cayenne pepper  
 30ml (2 tbsp) English mustard powder  
 300ml (1/2 pint) milk  
 salt and pepper  
 250g mascarpone cheese

### CHICKEN & MUSHROOM BAKE

- 1 Place the chicken, mushrooms, leeks, salt and pepper into a 2.5 litre (approx. 4 pints) bowl with 50g butter and cook on 100% for 8 minutes, stir twice.
- 2 Place 25g butter in a bowl and heat on 100% for 30 seconds until melted.
- 3 Stir in the flour, cayenne pepper and mustard.
- 4 Whisk in the milk and cook on 100% for 6 minutes, stir every 2 minutes until thick and smooth. Season with salt and pepper.
- 5 Mix the mascarpone cheese into the sauce and pour the sauce over chicken mixture. Mix well.
- 5 Place on the low rack and bake on DUAL - 1, 200°C, 50% for 20 minutes. Stir halfway through the cooking time.

## RECIPES

### Serves 4 - 6

30ml (2 tbsp) olive oil  
 175g onion, chopped  
 2 cloves garlic, crushed (see tip, page 48)  
 75g tomato purée  
 225g carrots, chopped  
 1 red pepper, seeded and sliced  
 1 green pepper, seeded and sliced  
 150g fresh baby sweetcorn, chopped  
 4 sticks celery, sliced  
 225g courgettes, sliced  
 5ml (1 tsp) ground cumin  
 10ml (2 tsp) mild chilli powder  
 2.5ml (1/2 tsp) cayenne pepper  
 400g canned, chopped tomatoes  
 225g canned haricot beans, drained  
 400g canned red kidney beans in chilli sauce  
 300ml (1/2 pint) hot vegetable stock  
 15ml (1 tbsp) cornflour blended with water

### VEGETABLE CHILLI

- 1 Place the oil, onion, garlic and tomato purée in a large bowl. Heat on 100% for 2 minutes.
- 2 Add the carrots, red and green pepper and sweetcorn, mix well. Cover and cook on 100% for 3 minutes.
- 3 Stir in the remaining ingredients (apart from the cornflour). Mix well and cook on 70% for 20 minutes, stir 3 - 4 times during cooking.
- 4 Add the blended cornflour, mix well and cook on 100% for 5 - 6 minutes.

Serve hot with rice or as a filling for tacos.

#### Microwave Tip: Heating taco shells

Place 8 - 10 pre-cooked crisp taco shells on kitchen paper on the turntable. Heat on 100% for 1 1/2 - 2 minutes until warm. Spoon in filling as preferred.

### Serves 4 - 6

10ml (2 tsp) olive oil  
 175g onion, chopped  
 2 cloves garlic, crushed (see tip, page 48)  
 175g leeks, sliced  
 100g mushrooms, thickly sliced  
 10ml (2 tsp) chopped fresh basil  
 10ml (2 tsp) chopped fresh oregano  
 225g red split lentils  
 45ml (3 tbsp) tomato purée  
 800g canned chopped tomatoes  
 300ml (1/2 pint) hot vegetable stock  
 1 bay leaf  
 salt and pepper to taste  
 12 sheets lasagne (spinach)  
 600ml (1 pint) cheese sauce (see page 61)  
 50g cheddar cheese, grated

### RED LENTIL LASAGNE

- 1 Place the oil, onion and garlic in a bowl, cook on 100% for 2 minutes.
- 2 Add the leeks, mushrooms, basil, oregano and lentils and then cook on 100% for a further 5 minutes.
- 3 Stir in the purée, tomatoes, vegetable stock and the bay leaf.
- 4 Cover and cook on 70% for 20 minutes.
- 5 Season with salt and pepper then remove the bay leaf.
- 6 Make the cheese sauce.
- 7 Put a layer of the lentil mixture into the base of a deep, 25cm square dish. Cover with some lasagne and then some of the cheese sauce.  
Repeat, making the last layer cheese sauce, add the grated cheese.
- 8 Place on low rack and cook on DUAL - 1, 180°C, 30% for 25 minutes.

### Serves 4

500g tofu, drained  
 100g Mozzarella, thinly sliced  
 75g Danish Blue, thinly sliced  
 1 quantity Spicy Tomato Sauce (see page 61)

### STUFFED TOFU WITH SPICY TOMATO SAUCE

- 1 Cut tofu in half to make 4 pieces.
- 2 Slice each piece horizontally along one side to make a pocket. Fill each pocket with sliced cheese, place in a large flan dish. Pour in sauce.
- 3 Place on turntable, cook on 50% for 12 - 14 minutes.

## RECIPES

### Serves 2

2 baking potatoes (approx. 250g each)  
50g butter  
100g Double Gloucester cheese, finely chopped  
15ml (1 tbsp) chives, chopped  
50g mushrooms, finely chopped  
salt and pepper to taste

### CHEESY JACKETS

- 1 Prick each potato in several places. Place in a flan dish on low rack. Cook on DUAL - 1, 250°C, 50% for 20 minutes until brown and crispy. Turnover after 7 minutes.
- 2 Halve each potato and scoop the flesh into a bowl, add the butter, cheese, chives and mushrooms, mix well. Season. Pile the mixture back into the potato skins.
- 3 Place the filled potatoes in a flan dish on the low rack. Cook on DUAL - 2, 30% for 10 minutes until brown and crispy.

**Cheese & sweetcorn jackets:** Omit the Double Gloucester cheese, chives and mushrooms. Add 100g of grated Cheddar cheese and 50g sweet corn kernels at Stage 2.

### Cook's Tip: Wooden Skewers

To remove food easily from wooden skewers, soak the skewers in water for 30 minutes prior to using them.

### Serves 4

600g canned, chopped tomatoes  
150g red pesto  
300g sun-dried tomatoes, drained and chopped  
salt and pepper to taste  
600g fresh ravioli (meat or vegetarian)  
600ml (1 pint) cheese sauce (see page 61)  
150g mozzarella cheese

### TOMATO, PASTA LAYER

- 1 Empty the tomatoes into a large bowl and cook on 100% for 8 minutes to reduce the juice.
- 2 Combine the Pesto and sun-dried tomatoes with the tomatoes and season.
- 3 Spread a 1/2 of this sauce over the base of a greased 25cm square dish, then place a single layer of ravioli. Next, spread 1/2 of the cheese sauce over the ravioli. Layer until all ingredients have been used, with the last layer being cheese sauce.
- 4 Sprinkle the grated mozzarella all over and place on the low rack. Cook on DUAL - 1, 220°C, 30% for 25 minutes.

### Serves 4 - 6

300g short crust pastry  
6 rashers of bacon, chopped  
125g onion, finely chopped  
4 eggs (medium)  
300ml (1/2 pint) milk  
salt and pepper to taste  
5ml (1 tsp) dried mixed herbs (see tip, page 55)  
225g Cheddar cheese, grated

### QUICHE LORRAINE

- 1 Preheat the oven to 200°C.
- 2 Line a 25cm flan dish with pastry, place on the low rack and cook on 200°C for 10 minutes.
- 3 Place bacon and onion in a bowl, cook on 100% for 3 minutes.
- 4 Place eggs, milk, seasoning in a bowl, mix well.
- 5 Spread bacon and onion evenly over the pastry. Pour egg mixture over, top with grated cheese.
- 6 Place on the low rack, and cook on DUAL - 1, 220°C, 30% for 25 minutes until set and brown.

**Stilton & mushrooms:** Replace bacon with 125g sliced mushrooms and Cheddar with Stilton.

## RECIPES

### Serves 4

1 aubergine, thickly sliced  
 cooking salt  
 3 x 30ml (2 tbsp) vegetable oil  
 1 red pepper, large chunks  
 1 yellow pepper, large chunks  
 3 courgettes, thickly sliced  
 125g onion, sliced  
 100g mushrooms, thickly sliced  
 225g leeks, sliced  
 2 cloves garlic, crushed (see tip, page 48)  
 350g pasta (bows, shells, or tubes), cooked  
 100 g feta cheese, crumbled

### MEDITERRANEAN PASTA

- 1 Place the aubergines in a colander, sprinkle with salt and leave to drain for 30 minutes, pat dry with kitchen paper.
- 2 Grease the turntable with 30ml (2 tbsp) oil and spread the peppers evenly on the turntable.
- 3 Cook using GRILL - 3 for 10 minutes, turnover halfway through cooking, leave on one side until needed. Repeat this process for the courgette and aubergine slices.
- 4 Place the onion, mushrooms, leeks and garlic into a 2.5 litre (approx. 4 pint) casserole dish, mix well and cook on 100% for 5 minutes, stirring once.
- 5 Add the peppers, courgettes, aubergine, pasta and cheese to the bowl and cook on 100% for 8 minutes, stirring twice.

### Serves 4

125g onion, chopped  
 2 cloves garlic, crushed (see tip, page 48)  
 25g butter  
 450g lean minced beef  
 100g mushrooms, chopped  
 15ml (1 tbsp) tomato purée  
 400g canned chopped tomatoes  
 150ml (1/4 pint) hot beef stock  
 salt and pepper to taste  
 12 pieces of lasagne  
 300ml (1/2 pint) cheese sauce (see page 61)  
 extra grated cheese to sprinkle  
 15ml (1 tbsp) fresh oregano, chopped to garnish

### CANNELLONI

- 1 Place onion, garlic and butter in a bowl, heat on 100% for 2 minutes. Add the mince, cook on 100% for 7 minutes, stir halfway through cooking.
- 2 Add mushrooms, purée, tomatoes, stock and seasoning. Cook on 70% for 25 minutes until thickened, stir every 5 minutes.
- 3 Place 3 - 4 pieces of lasagne in a bowl, cover with boiling water. Cook on 100% for 4 minutes until tender enough to bend. Remove from water, dry on kitchen paper. Repeat for the remaining lasagne.
- 4 Place a large spoonful of meat mixture at one end of a piece of lasagne, roll up and place seam side down in a deep, square 25cm dish. Repeat for remaining lasagne. Place any remaining meat around the filled lasagne.
- 5 Pour the cheese sauce on top of the filled lasagne. Sprinkle generously with cheese and oregano.
- 6 Place on low rack, cook on DUAL - 1, 220°C, 70% for 20 minutes until brown and crispy.

### Serves 4

4 beef tomatoes  
 125g white long grain rice, cooked  
 50g cooked ham, chopped  
 50g peas  
 15ml (1 tbsp) fresh oregano, chopped  
 salt and pepper to taste  
 75g Mozzarella cheese, chopped  
 15ml (1 tbsp) fresh oregano, chopped to garnish

### STUFFED TOMATOES

- 1 Slice the top of each tomato and scoop out the flesh into a bowl, stir in the rice, ham, peas, oregano, salt and pepper.
- 2 Fill each tomato shell with the rice mixture and place in a large flan dish. Sprinkle generously with the Mozzarella cheese and oregano.
- 3 Place on the low rack and cook on DUAL - 2, 50% for 10 minutes until the tomatoes are tender and the cheese is brown and crispy.



## RECIPES

### Serves 4 - 6

450g carrots, sliced  
450g swede, diced  
350g celery, sliced  
225g onion, sliced  
1.2 litres (2 pints) hot vegetable stock  
250g cous cous

### VEGETABLE COUS COUS

- 1 Place the carrots, swede, celery, onion and stock into a 3 litre (5 pint) casserole dish, mix well and cook on 70% for 20 minutes, stirring twice.
- 2 Add the cous cous, mix well and cook on 70% for 10 minutes.

Serve hot as an accompaniment or cold as a salad.

### Microwave Tip: Drying breadcrumbs

Spread 100g fresh breadcrumbs evenly over a large plate. Heat on 100% for 2 - 3 minutes, stir every minute until crispy.

### Serves 4

30ml (2 tbsp) vegetable oil  
10ml (2 tsp) ground cinnamon  
10ml (2 tsp) ground coriander  
5ml (1 tsp) cayenne pepper  
10ml (2 tsp) sesame seeds  
5ml (1 tsp) caraway seeds  
50g butter  
1.3cm fresh root ginger, peeled & grated  
2 cloves garlic, crushed (see tip, page 48)  
675g cooked potatoes, cut into 2.5cm pieces  
pinch of salt

### SPICY POTATOES

- 1 Place the oil, cinnamon, coriander, cayenne pepper, sesame and caraway seeds in a 2.5 litre (approx. 4 pint) casserole dish, mix well. Heat on 100% for 1 minute.
- 2 Add the butter, ginger and garlic. Cook on 70% for 3 minutes. Stir in the potatoes and salt.
- 3 Place the dish on the turntable, cook on 50% for 8 - 10 minutes, stir every 2 - 3 minutes.

Garnish with fresh chopped coriander, serve with grilled or roasted meats.

### Microwave Tip: Drying herbs

Place a handful of fresh herbs between two sheets of kitchen paper on the turntable. Heat on 70% for 3 minutes until dry. Ensure the herbs do not become too dry. Woody herbs will take a little longer.

### Serves 4

15ml (1 tbsp) sunflower oil  
1 clove garlic, crushed (see tip, page 48)  
2 medium carrots, cut into strips  
150g fresh baby sweetcorn  
100g button mushrooms, halved  
50g beansprouts  
100g mange-tout  
1 red pepper, seeded and thinly sliced  
1 yellow pepper, seeded and thinly sliced  
6 spring onions, chopped  
100g canned water chestnuts, sliced  
2 sticks celery, sliced  
225g canned pineapple chunks  
300g cabbage, shredded  
1 quantity of sweet and sour sauce (see page 61)

### SWEET & SOUR VEGETABLES

- 1 Place the oil, garlic, carrots and sweetcorn in a large bowl and mix well. Cover and cook on 100% for 4 - 5 minutes.
- 2 Stir in the mushrooms, beansprouts, mange-tout, red and yellow pepper, spring onion, chestnuts, celery, pineapple and cabbage.
- 3 Cover and cook on 100% for 6 - 8 minutes until the vegetables are tender, stir thoroughly halfway through cooking and add the sweet and sour sauce.

## RECIPES

### Serves 6

125g dried figs, roughly chopped  
 125g dried apricots, roughly chopped  
 100g raisins  
 100g currants  
 60ml (4 tbsp) brandy  
 75g plain flour  
 2.5ml (1/2 tsp) allspice  
 2.5ml (1/2 tsp) grated nutmeg  
 2.5ml (1/2 tsp) ground cinnamon  
 50g fresh breadcrumbs  
 75g shredded suet  
 100g soft brown sugar  
 50g blanched almonds, roughly chopped  
 grated rind of 1 medium orange  
 grated rind of 1 medium lemon  
 1 eating apple, grated  
 15ml (1 tbsp) black treacle  
 1 egg (medium), beaten

### FIGGY PUDDING

- 1 Place figs, apricots, raisins, currants, and brandy in a large bowl, mix well. Leave for 2 hours.
- 2 Place the flour, spices, breadcrumbs, suet, sugar, almonds, orange and lemon rind and apple in a bowl, mix well. Stir into the dried fruit mixture along with the treacle and beaten egg.
- 3 Grease 1.2 litre (2 pints) pudding basin and line the base with a circle of kitchen paper. Spoon in the pudding mixture, smooth the surface and cover with cling film.
- 4 Cook on 50% for 16 - 17 minutes until firm to the touch.

Serve with brandy sauce, see page 69.

#### Microwave Tip: Reheating Christmas pudding

Place a 500g (1lb 2oz) pudding in a shallow flan dish. Cover and heat on 70% for 3 - 4 minutes.

### Serves 6

**PASTRY:**  
 150g butter  
 350g flour  
 50g caster sugar  
 2 egg yolks (medium)  
 cold water to mix  
**FILLING:**  
 1kg cooking apples, peeled and sliced  
 100g demerara sugar  
 10ml (2 tsp) ground cinnamon (optional)  
 grated rind of 1 orange (optional)  
 1 egg (medium) mixed with a little milk to glaze  
 demerara sugar

### APPLE PIE

- 1 For pastry, rub butter into flour until mixture resembles breadcrumbs. Stir in sugar and bind with egg yolk. Add enough cold water to make a soft, but not sticky, dough. Chill whilst making the filling.
- 2 For filling, combine apple, sugar, cinnamon (optional) and orange rind (optional) in a large bowl. Cook on 100% for 8 minutes, stirring twice.
- 3 Line the base of a greased 20cm x 2.5cm pie dish with half the pastry. Cook the pastry base on 50% for 7 - 8 minutes. Spoon in apple mixture, roll out remaining pastry and cover.
- 4 Pinch pastry edges to seal and make a slit in the centre with a sharp knife. Brush with egg mixture to glaze and sprinkle generously with sugar.
- 5 Place on the low rack, cook on DUAL - 1, 220°C, 10% for 20 - 25 minutes, until golden brown.

### Makes 675g

150g milk chocolate, broken into pieces  
 100g butter, melted  
 450g icing sugar, sieved  
 45ml (3 tbsp) milk

### CHOCOLATE FUDGE

- 1 Place the chocolate in a bowl and heat on 100% for 2 minutes, stir every 30 seconds until melted.
- 2 Stir in butter, icing sugar and milk. Heat on 100% for 2 - 3 minutes, stir vigorously every minute until the mixture is thick and glossy.
- 3 Pour into a greased, rectangular 20 x 15cm dish, chill to set before cutting.

## RECIPES

### Serves 6 - 8

150ml (1/4 pint) sunflower oil  
 225g soft brown sugar  
 3 eggs (medium), beaten  
 175g self raising flour  
 5ml (1 tsp) bicarbonate of soda  
 1.25 ml (1/4 tsp) salt  
 10ml (2 tsp) cinnamon  
 300g carrots, grated  
 100g walnut halves, roughly chopped  
**ICING:**  
 225g cream cheese (see tip, page 51)  
 grated rind of 1 lemon  
 5ml (1 tsp) lemon juice  
 30ml (2 tbsp) icing sugar  
 25g walnuts, finely chopped to sprinkle

### MOIST CARROT CAKE

- 1 Combine the oil, sugar and eggs. Fold in the flour, bicarbonate of soda, salt and cinnamon. Add the carrots and walnuts, mix well.
- 2 Grease and line a 20cm soufflé dish with greaseproof paper, pour in the cake mixture.
- 3 Place on turntable, cook on DUAL - 1, 180°C, 30% for 26 minutes. Allow to cool before decorating.
- 4 To prepare icing, combine cream cheese, lemon rind, lemon juice and icing sugar until smooth. Spread on top of the cake, sprinkle with walnuts.

If iced with cream cheese, keep cake refrigerated. Eat within 2 days.

#### Carrot & Courgette:

Substitute 150g of the carrots with 150g grated courgettes. Add with the carrots and walnuts in stage 1.

### Serves 6 - 8

225g margarine  
 225g caster sugar  
 7.5ml (1 1/2 tsp) vanilla essence  
 4 eggs (medium), beaten  
 100g plain flour  
 50g cocoa powder  
 2.5ml (1/2 tsp) baking powder  
 150g cooking chocolate, chunks

### CHOCOLATE BROWNIES

- 1 Combine the margarine, sugar, vanilla essence and eggs together until smooth.
- 2 Stir in the remaining ingredients.
- 3 Grease and line the base of a deep, square 20cm dish with greaseproof paper, spoon in the brownie mixture and smooth the surface.
- 4 Place on the turntable, cook on DUAL - 1, 180°C, 30% for 15 minutes.

### Serves 8

250g self raising flour  
 Large pinch of salt  
 175g butter, cut into small pieces  
 100g ground almonds  
 100g caster sugar  
 2 eggs (medium), beaten  
 60ml (4 tbsp) milk  
 10ml (2 tsp) almond essence  
 150g white chocolate, chopped  
 300g fresh raspberries  
 Icing sugar, for dusting

### RASPBERRY & CHOCOLATE CAKE

- 1 Grease a 20cm round cake tin and line the base with greaseproof paper.
- 2 Sift the flour and salt into a large bowl. Rub the butter into the flour until the mixture resembles breadcrumbs. Stir in the ground almonds and sugar.
- 3 Beat the eggs, milk and almond essence together and mix into the flour mixture. Add the chocolate and raspberries and mix in gently.
- 4 Spread the mixture into the cake tin, place on the low rack and cook on DUAL - 1, 180°C, 50% for 25 - 30 minutes. Allow the cake to cool. Dust with icing sugar.

## RECIPES

### Serves 4 - 6

100g margarine  
100g caster sugar  
2 eggs (medium), beaten  
100g self raising flour  
30 - 45ml (2 - 3 tbsp) water

### PLAIN MICROWAVE CAKE

- 1 Cream margarine and sugar, beat in the eggs. Fold in the flour and water. Grease and line the base of a 18cm cake dish with kitchen paper. Spoon mixture into dish and smooth.
- 2 Cook on 100% for 4 - 5 minutes until firm. Allow to cool slightly before turning out.

### Serves 6

175g butter  
175g caster sugar  
3 eggs (medium)  
175g plain flour  
5ml (1 tsp) baking powder  
100g glacé cherries, quartered  
75g ground almonds  
5ml (1 tsp) almond essence  
15ml (1 tbsp) milk

### CHERRY & ALMOND CAKE

- 1 Cream the butter and sugar together until light and fluffy, beat in the eggs.
- 2 Fold in flour and baking powder, stir in the cherries, ground almonds, almond essence and milk.
- 3 Grease and line the base of a 18cm cake dish with greaseproof paper. Spoon in the cake mixture and smooth the surface.
- 4 Place on the turntable, cook on DUAL - 1, 200°C, 30%, for 17 minutes.

### Serves 6 - 8

175g margarine  
100g caster sugar  
225g self raising flour  
50g milk chocolate, finely chopped  
25g walnuts, finely chopped

The biscuits will be soft when hot but will harden as they cool.

### CHOCOLATE CHIP COOKIES

- 1 Cream margarine and sugar until light and fluffy. Stir in the flour, chocolate and walnuts to make a soft but firm dough.
- 2 Divide mixture into 8 even sized balls, place apart in two large flan dishes and flatten slightly.
- 3 Place one dish on low rack and the other on the high rack. Bake on CONVECTION 180°C for 30 minutes until golden brown around the edges. Swap the dishes round after 20 minutes.
- 4 Allow to cool before removing from the dish.

### Serves 4 - 6

100g butter  
75g golden syrup  
175g black treacle  
225g plain flour  
10ml (2 tsp) ground ginger  
5ml (1 tsp) bicarbonate of soda  
25g caster sugar  
150ml (1/4 pint) milk  
2 eggs (medium), beaten

### GINGERBREAD

- 1 Place the butter, syrup and treacle into a bowl, heat on 100% for 2 minutes and stir well.
- 2 In a separate bowl, place the flour, ginger, bicarbonate and sugar.
- 3 Add the milk into the melted syrup mixture then add the eggs and mix well.
- 4 Stir into the dry ingredients and beat thoroughly.
- 5 Pour into a greased and lined 20cm square dish.
- 6 Place on the low rack and cook on DUAL - 1, 180°C, 30%, for 18 minutes.

## RECIPES

### Serves 4

325g potato, cooked and mashed  
 325g parsnips, cooked and mashed  
 225g self raising flour  
 2 cloves garlic, crushed (see tip, page 48)  
 10ml (2 tsp) whole grain mustard  
 2 eggs (medium), beaten  
 75ml (5 tbsp) milk  
 5ml (1 tsp) fresh parsley, chopped to sprinkle

### POTATO BREAD

- 1 Place the potato, parsnips, flour, garlic and mustard in a large bowl, mix well.
- 2 Add the egg and milk, mix to form a soft dough. Knead the dough into a round shape approx. 20cm in diameter. Place in a 25cm flan dish, sprinkle with parsley.
- 3 Place on the low rack and cook on DUAL - 1, 220°C, 30% for 25 minutes until golden.

Serve with soup, cheese or salad.

### Serves 6 - 8

175g figs, chopped  
 150ml (1/4 pint) boiling water  
 225g plain flour  
 125g wholemeal flour  
 125g caster sugar  
 2.5ml (1/2 tsp) salt  
 2.5ml (1/2 tsp) bicarbonate of soda  
 100g butter  
 125g walnuts, roughly chopped  
 150ml (1/4 pint) milk  
 1 egg (medium), beaten

### FIG & WALNUT BREAD

- 1 Place figs in a large bowl, add the boiling water, leave aside to cool.
- 2 Preheat the oven to Convection 180°C.
- 3 Place flours, sugar, salt and bicarbonate of soda in a bowl, mix well. Rub in butter until mixture resembles fine breadcrumbs, stir in walnuts.
- 4 Add the fig mixture, milk and egg, mix well.
- 5 Grease and line the base of a 1.5 litre (2 1/2 pint), straight-sided loaf dish with greaseproof paper. Spoon in loaf mixture and smooth the surface.
- 6 Place on the low rack, cook in a preheated oven on DUAL - 1, 180°C, 50% for 20 minutes, until a skewer comes out cleanly.

Serve sliced, spread generously with butter.

### Microwave Tip: Toasting coconut

Spread 100g desiccated coconut on a plate. Heat on 100% for 2 - 3 minutes, stir every minute.

### Serves 4

225g wholemeal self raising flour  
 150g medium oatmeal  
 2.5ml (1/2 tsp) salt  
 2.5ml (1/2 tsp) bicarbonate of soda  
 50g butter  
 120ml (4fl.oz) natural yoghurt  
 90ml (6 tbsp) milk  
 1 egg (medium), beaten to glaze  
 sesame seeds to sprinkle

### SODA BREAD

- 1 Combine flour, oatmeal, salt, bicarbonate of soda in a large bowl. Rub in the butter.
- 2 Add the yoghurt and milk, mix to form a soft but not sticky dough.
- 3 Knead lightly into a round shape approx. 20cm in diameter. Place in a greased 25cm flan dish.
- 4 Use a knife to mark into 8 wedges, cut only halfway through the dough. Glaze surface with egg, sprinkle with sesame seeds.
- 5 Place on low rack, bake in a preheated oven on DUAL - 1, 200°C, 10% for 17 - 18 minutes until golden.

Serve with cheese and a salad.

## RECIPES

### Makes 8 biscuits

#### BISCUITS:

100g butter  
50g caster sugar  
100g self raising flour  
25g cocoa powder  
2.5ml (1/2 tsp) vanilla essence

#### BUTTERCREAM:

50g butter  
75g icing sugar  
30ml (2 tbsp) cocoa powder

### CHOCOLATE CREAMS

- 1 Grease two small round baking trays
- 2 Combine all the biscuit ingredients in a bowl, rub in then mix well.
- 3 Preheat the oven to CONVECTION 200°C.
- 4 Divide the mixture into 16 even sized pieces and roll into balls, Place apart on two greased baking trays. Flatten each ball slightly with a fork.
- 5 Place one tray on the low rack and the other on the high rack. Bake at CONVECTION 200°C for 12 minutes. Rotate and change the trays over halfway through cooking time.
- 6 To prepare the butter cream, cream the butter and icing sugar until fluffy. Add the cocoa and mix well.
- 7 When biscuits are cool, spread with butter cream and sandwich together to make 8 chocolate creams.

### Serves 4

1.5 litres (2 pints) milk  
200g pudding rice  
75g caster sugar  
50g butter  
5ml (1 tsp) ground nutmeg (optional)

### RICE PUDDING

- 1 Place the milk into a 1.5 litre (2 1/2 pint) casserole dish. heat on 100% for 8 minutes.
- 2 Stir in the rice, sugar and butter. Heat on 100% for 5 minutes.
- 3 Place on the low rack and cook on DUAL - 1, 180°C, 30% for 60 minutes. Stir 2 - 3 times during cooking and again at the end of cooking.
- 4 Sprinkle with ground nutmeg to serve.

### Makes 12 scones

450g self raising flour  
100g butter  
100g caster sugar  
100g sultanas  
2 eggs (medium), beaten with milk to make 300ml (1/2 pint)  
1 egg (medium), beaten to glaze

### FRUIT SCONES

- 1 Preheat the oven to 220°C.
- 2 Place the flour in the bowl and rub in the butter.
- 3 Add the sugar and the fruit.
- 4 Mix together the milk and egg.
- 5 Make a well in the flour, add almost all of the liquid and mix with a round bladed knife.
- 6 On a floured surface, knead the dough very lightly until it is just smooth.
- 7 Divide the mixture in two, flatten until approx. 2cm thick, then cut each peice of dough into seven rounds (approx. 6.2cm each).
- 8 Grease two flan dishes, place seven scones in each dish. Place one dish on the high rack and the other dish on the low rack.
- 9 Cook at 220°C for 12 minutes, then swap the position of the dishes and cook for a further 10 minutes, until well-risen and brown.

**Wholemeal scones:** Substitute white self raising flour with wholemeal self raising flour, omit raisins.

**Cheese & chive scones:** Omit sugar and sultanas. Add 175g grated Cheddar cheese, 15ml (1 tbsp) dried chives, salt and pepper at Stage 2.

## RECIPES

### Makes 300ml (1/2 pint)

25g butter  
 25g plain flour  
 300ml (1/2 pint) milk  
 salt and pepper to taste

### WHITE SAUCE

- 1 Place the butter in a bowl and heat on 100% for 1 minute, until melted.
- 2 Stir in the flour and whisk in the milk. Cook on 100% for 8 minutes, stir every 2 minutes until thick and smooth. Season with salt and pepper to taste.

**Cheese sauce:** Stir in 75g grated cheese and 5ml (1 tsp) mustard powder at Stage 2. Serve with vegetables, fish or meat.

**Parsley sauce:** Stir 15 - 30ml (1 - 2 tbsp) chopped parsley into the finished sauce. Serve with fish.

**Onion sauce:** Stir 225g cooked onion, finely chopped, into the finished sauce. Heat on 100% for 1 minute before serving. Serve with meat or vegetables.

**Sweet white sauce:** Omit salt and pepper from basic recipe. Add 15 - 30ml (1 - 2 tbsp) caster sugar at Stage 2. Serve with puddings as an alternative to custard.

### Makes 600ml (1 pint)

125g onion, finely chopped  
 1 green pepper, finely chopped  
 2 cloves garlic, crushed (see tip, page 48)  
 30g butter  
 30g plain flour  
 30ml (2 tbsp) white wine vinegar  
 30ml (2 tbsp) soy sauce  
 300ml (1/2 pint) hot chicken stock  
 50g soft dark brown sugar

### SWEET & SOUR SAUCE

- 1 Place the onion, green pepper, garlic and butter in a bowl, mix well. Cook on 100% for 2 minutes.
- 2 Stir in the flour, gradually add the vinegar, soy sauce, stock and sugar. Cook on 100% for 3 - 4 minutes, stir every minute until the mixture has thickened. Blend in a food processor for a smoother sauce.

### Makes 600ml (1 pint)

3 rashers bacon, chopped (optional)  
 150g carrot, chopped  
 225g onion, chopped  
 2 cloves garlic, crushed (see tip, page 48)  
 800g canned, chopped tomatoes  
 300ml (1/2 pint) red wine  
 45 - 60ml (3 - 4 tsp) medium chilli sauce  
 10ml (2 tsp) whole grain mustard  
 30ml (2 tbsp) tomato purée

### SPICY TOMATO SAUCE

- 1 Place bacon, carrot, onion and garlic in a large bowl, cover and heat on 100% for 3 minutes.
  - 2 Add all other ingredients to bacon mixture and mix well. Cook 70% for 35 minutes.
  - 3 Blend in a food processor until smooth, return to bowl and cook on 70% for 3 minutes.
- Serve with stuffed tofu, see page 59.

### Makes 300ml (1/2 pint)

25g butter  
 45ml (3 tbsp) whole grain mustard  
 200ml (7fl.oz) soured cream  
 salt and pepper to taste

### MUSTARD SAUCE

- 1 Place butter in a bowl, heat on 100% for 30 seconds. Add the mustard, soured cream, salt, and pepper, mix well.
- 2 Cook on 100% for 4 minutes, stir every minute, until smooth and thick.

Serve with meat or fish.

## RECIPES

### Makes 450ml (3/4 pint)

75g Blue Stilton cheese, finely chopped  
300ml (1/2 pint) soured cream  
150ml (1/4 pint) white wine  
15ml (1 tsp) cornflour blended with water  
30ml (2 tbsp) fresh parsley, chopped  
salt and pepper to taste

### BLUE CHEESE SAUCE

- 1 Place the cheese, cream wine, cornflour and parsley in a bowl, mix well. Season.
- 2 Heat on 100% for 8 minutes, stir twice during cooking and again before serving.

Ideal served with pasta.

### Makes 600ml (1 pint)

50g butter  
50g plain flour  
75g brown sugar  
15ml (1 tsp) golden syrup  
150ml (1/4 pint) double cream  
300ml (1/2 pint) milk  
60ml (4 tbsp) brandy to taste

### BRANDY SAUCE

- 1 Place butter in a bowl, heat on 100% for 1 minute until melted. Stir in flour, heat on 100% for 1 minute.
- 2 Combine sugar, syrup, cream and milk, heat on 100% for 2 minutes.
- 3 Gradually add cream mixture to the butter and flour mixture. Heat on 100% for 5 - 6 minutes, stir every minute until smooth and thick. Stir in brandy.

Serve hot with Figgy Pudding (page 56).

### Microwave Tip: Softening avocados

Pierce an unpeeled avocado in several places. Place on the turntable and heat on 100% for 1 minute. Allow to cool before peeling.

### Makes 675g

675g strawberries, washed, hulled and quartered  
45ml (3 tbsp) lemon juice  
675g preserving sugar

### STRAWBERRY JAM

- 1 Place strawberries and lemon juice in a very large bowl.
- 2 Heat on 100% for 5 minutes until strawberries have softened. Add the sugar, mix well.
- 3 Cook on 70% for 40 minutes until setting point (\*) is reached, stir every 4 - 5 minutes.
- 4 Pour into hot, clean jars. Cover, seal and label.

**Raspberry jam:** Replace 675g strawberries with 675g raspberries.

### \* Setting point

To determine, place 5ml (1 tsp) jam onto a saucer. Chill. Move surface of jam with finger, if it wrinkles, setting point has been reached.

### Makes 675g

100g butter  
450g caster sugar  
45ml (3 tbsp) cornflour  
juice of 4 medium lemons  
grated rind of 2 lemons  
4 egg yolks (medium), beaten

### LEMON CURD

- 1 Place butter and sugar in a bowl. Heat on 100% for 2 minutes until melted.
- 2 Mix cornflour, lemon juice and rind. Stir into the butter and sugar mixture. Heat on 100% for 2 minutes until sugar has dissolved. Cool slightly.
- 3 Beat in the egg yolks, cook on 50% for 10 - 12 minutes, stir every 2 minutes until thickened.
- 4 Pour into hot, clean jars. Cover, seal and label.



## GUARANTEE

Sharp Electronics (UK) Ltd. ("Sharp") guarantees that for a period of 12 months from the date of purchase the enclosed product will be free from defects in materials and workmanship. Sharp agrees to provide for the repair or, at its option, the replacement of a defective product. Sharp reserves the right to replace defective parts, or the product, with new or refurbished items. Items that are replaced become the property of Sharp.

To benefit from this guarantee, any fault that occurs must be notified to Sharp, or its appointed Service Facility, within one year from the date the product was purchased. Proof of purchase, such as a receipt or invoice, must be provided.

If the product is exchanged, the replacement shall be covered by the unexpired portion of the original guarantee.

In the unlikely event of the product requiring repair, please contact the supplier from whom it was purchased. Where this is not possible, please contact an appointed Service Facility. Details of Service Facilities appointed by Sharp can be obtained from [www.sharp.co.uk/customersupport/service](http://www.sharp.co.uk/customersupport/service) or by contacting the **Sharp Customer Information Centre** whose details are given below.

This guarantee shall only apply to faults that are due to inferior workmanship or materials. It does not cover faults or damage caused by accident, misuse, fair wear and tear, neglect, tampering with the product, or repair other than by a Service Facility appointed by Sharp.

The product is intended for private domestic use only. The guarantee will not apply if the product is used in the course of a business, trade or profession.

The guarantee does not cover:

- Glass/ceramic turntables, as they can be damaged by handling/cleaning methods.
- Faults resulting from inadequate cleaning. Regular cleaning is required to prevent a build up of food residue that can also affect the performance of the product.
- Carriage costs to or from the repair centre.

No person has any authority to vary the terms or conditions of this guarantee.

This guarantee is offered as an additional benefit to your statutory rights, and does not affect these rights in any way.

You may not transfer your rights or obligations under this warranty to anyone else.

If you have any difficulty operating the product, or would like information on other Sharp products, please telephone the Sharp Customer Information Centre on the number given below.

### Sharp Customer Information Centre

**Website:** [www.sharp.co.uk/customersupport](http://www.sharp.co.uk/customersupport)

**Telephone:** 08705 274277 (01 676 0648 in Southern Ireland)

Sharp Electronics (UK) Ltd is a company registered in England under number 965877  
whose registered office is at

Sharp House, Thorp Road, Newton Heath, Manchester, M40 5BE.

## SPECIFICATIONS

AC Line Voltage .....Single phase 230-240V, 50Hz

Power Consumption:

Microwave .....	1.45kW
Top Grill .....	1.00kW
Bottom Grill .....	0.55kW
Convection .....	1.525kW
Top and Bottom Grill .....	1.50kW
Microwave/Top Grill .....	2.40kW
Microwave/Bottom Grill .....	1.95kW
Microwave/Convection .....	2.425kW

Input Current:

Microwave .....6.5A

Output Power:

Microwave .....	900W (IEC 60705)
Top Grill .....	1000W
Bottom Grill .....	500W
Convection .....	1450W

MAFF Heating Category .....E

Microwave Frequency .....2450MHz \* (Group 2/Class B)

Outside Dimensions .....520(W) x 309(H) x 488(D)mm

Cavity Dimensions .....349(W) x 207(H) x 357(D)mm \*\*

Oven Capacity .....26 litres \*\*

Cooking uniformity .....Turntable diameter 325mm

Weight .....Approx. 20kg

\* This Product fulfils the requirement of the European standard EN55011.

In conformity with this standard, this product is classified as group 2 class B equipment.

Group 2 means that the equipment intentionally generates radio-frequency energy in the form of electromagnetic radiation for heating treatment of food.

Class B equipment means that the equipment is suitable to be used in domestic establishments.

\*\* Internal capacity is calculated by measuring maximum width, depth and height.

Actual capacity for holding food is less.

This oven complies with the requirements of Directives 89/336/EEC and 73/23/EEC as amended by 93/68/EEC.



As part of a policy of continuous improvement, we reserve the right to alter design and specifications without notice.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording, translating or other means without prior permission from SHARP Electronics (U.K.) Ltd.

The illustrations, technical information and data contained in this publication are, to our best knowledge, correct at the time of going to print.

The right to change specifications, at any time, without notice, is reserved a part of our policy of continuous development and improvement.





# SHARP


**Sharp Electronics (U.K.) Ltd**  
Manchester, U. K.

**U.K.:** 08705 274277 (office hours)

**Ireland:** 01 676 0648 (office hours)

**Website:** [www.sharp.co.uk/customersupport](http://www.sharp.co.uk/customersupport)

SHARP MANUFACTURING  
is a member of:



PRINTED IN THE UK  
TINS-A403URR0

# SHARP


**Sharp Electronics (U.K.) Ltd**  
Manchester, U. K.

**U.K.:** 08705 274277 (office hours)

**Ireland:** 01 676 0648 (office hours)

**Website:** [www.sharp.co.uk/customersupport](http://www.sharp.co.uk/customersupport)

SHARP MANUFACTURING  
is a member of:



PRINTED IN THE UK  
TINS-A403URR0